

WorldSID Dummy Model Development

in Cooperation with

German Automotive Industry

A. Gromer, S. Stahlschmidt (DYNAmore GmbH);

P. Schuster (Dr. Ing. h.c. F. Porsche AG)

WorldSID^{50th} Dummy Model Development in Cooperation with German Automotive Industry

A. Gromer, S. Stahlschmidt

DYNAmore GmbH, Germany

P. Schuster

Dr. Ing. h.c. F. Porsche AG, Germany

1st October 2008

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Content

- Introduction
- Hardware test database
 - Material tests
 - Component tests
- Introduction of WSID 50th Version 0
- Dummy validation in selected tests
 - Sled tests
 - Barrier design
 - Abdomen calibration
- Conclusion

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Introduction

DYNAmore dummy models

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Introduction

The FAT

- FAT is abbreviation for:
German Association for Research on Automobile Technology
- FAT is part of the VDA
- VDA is: German Association of the Automotive Industry
- FAT was founded in 1971 to join scientific research for members
- VDA and FAT are located in Frankfurt
- Members:
 - OEMs: Audi, BMW, Daimler, Opel, Porsche, Volkswagen
 - Supplier
- Many working groups on different automotive research issues

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Introduction

The PDB and its work

- Partnership for Dummy Technology and Biomechanics
- Members



- Task

- Providing a WSID 50th finite element model for the crash codes used by the members
- Similar to known FAT projects
- Project budget over 1 100 000 \$

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Content

- Introduction
- **Hardware test database**
 - Material tests
 - Component tests
- Introduction of WSID 50th Version 0
- Dummy validation in selected tests
 - Sled tests
 - Barrier design
 - Abdomen calibration
- Conclusion

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany




Hardware test database

Material of the WorldSID

- Majority of the materials is rubber or rubber-like
 - Very few foam parts
 - Plastics
 - Neoprene
 - Nitinol
 - Rib damping material
 - Aluminum
 - Steel

Rubber parts





7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Hardware test database

Material tests


- Rubber materials:
 - *MAT_SIMPLIFIED_RUBBER
 - Stress-strain table, unloading curve

- **Foam materials:**

- *MAT_FU_CHANG_FOAM
 - Stress-strain table, unloading cure

- Nitinol:

- Shape Memory alloy
 - *MAT_SHAPE_MEMORY
 - 4 corner points



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Hardware test database

Material tests

- Tested materials
 - Rubbers, foams, Vinyl, Nitinol, rib damping material, Neoprene, ...



- Test types:
 - Static tension and compression
 - Dynamic tension and compression (0.001 1/s, 20 1/s, 100 1/s, 400 1/s)
 - For rubber-like materials additional compression tests with constrained lateral expansion



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Hardware test database

Arm tests

- Impactor test
- 3 different impact positions
- 2 different impactor masses



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Hardware test database

Head and neck assembly test

- Sled test
- Different pulses and pulse directions
- Blocking plate for limiting neck bending

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Hardware test database

Neck test example: 20 g – 75 degrees

- Head angular velocity about x-Axis (left) and y-acceleration (right)
- Upper neck load cell x-momentum (left), y-Force (right)

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Hardware test database

Neck calibration test

- Neck column with buffers and upper neck load cell
- Pendulum with honeycomb breaking system
- Evaluation of angles, acceleration, forces and momentum

0.0 ms

Point A

forward sliding rod

Point B

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Hardware test database

Neck calibration test

- Angular displacement about A (left) and B (right)
- Upper neck load cell x-momentum (left), y-Force (right, solid) and z-Force (right, dotted)


7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Hardware test database

Iliac wing test

- Pendulum test
- Test configuration with complete inner pelvis assembly
- Sacrum block is fixed
- 2 impact positions



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Hardware test database

Lumbar spine test

- Sled test
- Similar to head and neck assembly test
- Mass replacement for the upper torso
- Different pulses




7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Model validation

Rib assembly tests

- 1 shoulder, 3 thorax and 2 abdomen ribs
- Inner and outer rib bands consist of shape memory material Nitinol





7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Model validation

Rib assembly test matrix

- Pendulum: 2 different masses, 3 different impact velocities
- Number of tests: 4 ribs x 3 velocities x 2 masses x 5 angles = 120 load cases



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Model validation

Rib assembly tests – an example

- Separate validation of the inner rib band due to complex behavior
- Test configuration:

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Model validation

Rib assembly tests

- Rib component test at 3.5m/s pendulum velocity; deflection [mm] (left), acceleration [g] (right)

- Rib component test at 6.0m/s pendulum velocity; deflection [mm] (left), acceleration [g] (right)

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Model validation

Rib assembly tests – an example

- Test of a thorax rib assembly

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Content

- Introduction
- Hardware test database
 - Material tests
 - Component tests
- **Introduction of WSID 50th Version 0**
- Dummy validation in selected tests
 - Sled tests
 - Barrier design
 - Abdomen calibration
- Conclusion


7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Introduction of WSID 50th Version 0

WSID 50th model overview

- Based on the CAD data of ISO 15830/2005
- Model size: WSID ES2re
 - Nodes ~135000 ~100000
 - Shell ~97500 ~95000
 - Hexa ~64200 ~25000
 - Tetra ~40000 ~140000
 - Parts ~560 ~250
- Very few tetrahedron elements
- 54 sensor signals extractable
- Uses FAT material data (ES2, BioRID)




7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Introduction of WSID 50th Version 0

WSID 50th model development

- Element length between 4mm to 7mm
- Model time step: 1 microsecond
- Reducing CPU time by meshing pelvis flesh with hexaedrons



~13 000 hexas ~40 000 tetras

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Introduction of WSID 50th Version 0

WSID 50th model development

- Project was launched in 2006
- Monthly workshop meetings
- 2.5 engineers are currently working on the WSID development
- Milestones:
 - September 2007: complete mesh of the WorldSID is available
 - April 2008: Version 0 is finished
 - November 2008: first real production release will be available
 - Following years: updates
- Complete dummy development on LS-Dyna 971.R2

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Content

- Introduction
- Hardware test database
 - Material tests
 - Component tests
- Introduction of WSID 50th Version 0
- **Dummy validation in selected tests**
 - Sled tests
 - Barrier design
 - Abdomen calibration
- Conclusion


7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany



Dummy validation

Sled tests

- For the investigation of component interaction sled tests are necessary
- Many of the ES2 barriers are used for the WSID development




7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Dummy validation

Sled tests – new barrier design

- Additional barrier
- Due to FMVSS214 oblique pole test a new barrier shape was developed
- Typical intrusion profiles of all PDB members were collected




7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Dummy validation

Sled tests – new barrier design

- Wooden barrier with simplified shape generated out of the outlines
- Design supported by pre-simulations using the ES2-Dummy model
- Adjustment of heights and edge characteristics with respect to real crash scenarios




7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Dummy validation

Abdomen calibration test

- Simple pendulum test
- Dummy sits fully assembled with jacket on the WSID bench
- Pendulum mass 24.4kg, velocity 4.3m/s



7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Dummy validation

Abdomen calibration test

- Pendulum acceleration [g]
(left) , T12 acceleration [g]
(right)

- Upper abdomen rib deflection [mm] (left), lower abdomen rib deflection [mm] (right)

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Content

- Introduction
- Hardware test database
 - Material tests
 - Component tests
- Introduction of WSID 50th Version 0
- Dummy validation in selected tests
 - Sled tests
 - Barrier design
 - Abdomen calibration
- Conclusion

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

DYNA
MORE

Conclusion

- A large number of hardware and material test are defined
- Despite of a moderate number of elements the WSID 50th LS-Dyna model captures the hardware geometry very well
- More tests (sled, component) will be defined by using the experience from the Version 1 dummy model
- Version 1 of WSID 50th will be released in the fall of 2008
 - All material data from the tests will be included
 - Validation based on the first series of component tests
- Available at your local distributor

7. LS-DYNA User's Meeting
30th September - 1st of October 2008 in Bamberg, Germany

