

Emanuele Michelini (Vehicle Safety Institute – TU Graz)


Wednesday, June 22, 2022


Mechanical and electrical test procedures to characterise the behaviour of lithium-ion batteries

Information Day Battery Simulation 2022, Stuttgart



Motivation





- Reduction of factors involved → laboratory controlled environment
- Once the parameter to be measured and under which boundary conditions and loading has been identified, the test can be designed

- For simulation experiments is crucial:
 - Identify an appropriate measurement set-up (i.e. testbed)
 - Identify a mode of measurement of physical quantities for the determination of simulation parameters (i.e. sensors)
 - After testing, correctly interpret the results obtained


- Challenges of test design:
 - Reproducibility of test design
 - Precise measurement and setting of loadings
 - Possibility of measuring several physical quantities simultaneously
 - High accuracy and sampling rate of sensors and measuring devices

- Different factors influence battery behavior:
 - Thermal → Thermal tests
 - Electrical → Electrical tests
 - Mechanical → Mechanical tests





- Electrical quantities are the loadings that are controlled
- The two quantities that are controlled by appropriate sensors are current and voltage
- Exemplary approach



- Multi-step test protocol → a programmable cycling station is used



Determination of characteristic battery data:

- Capacitance determination
- Open Circuit Voltage (OCV) curves
- Internal resistance determination
- Electrochemical Impedance Spectroscopy (EIS)
- Classification of battery performance and safety

- Which parameters to measure?


It depends

- For example: capacity loss and internal resistance increase can be used to validate electrochemical models of cell ageing



- Mechanical quantities are the loadings that are controlled
- Examples of quantities that are monitored during testing are force, displacement, velocity, pressure
- Mechanical tests:
 - Various types of mechanical tests (e.g. compression, bending, indentation)
 - With impactor with different size and geometries (e.g. spherical, cylindrical, nail)
 - At different speed (quasi-static, dynamic)





Quasi-static mechanical test (Transverse compression)





Exemplary approach:

- Indentation tests with rectangular impactor on fresh and aged cells


Comparison of:

- Failure deformation
- Force increase
- Comparison of f-s curve
- Voltage drop




Quasi-static mechanical test

- Exemplary approach results aged compared to fresh:
 - Failure at higher deformations
 - Slight increase in average force at failure
 - Significant difference in onset of f-s curve
 - Deeper voltage drop



- Exemplary approach:
 - Indentation tests with cylindrical impactor on cell at different SOC
- Comparison of:
 - Failure deformation
 - Force increase
 - Comparison of thermal behaviour
- Results:
 - Failure for the fully charged cell required higher force and higher displacement
 - The fully charged cell goes into thermal runaway resulting in a high temperature increase





- Dynamic tests are close to the real behaviour of an automotive battery



Facts:


- Sled velocity: up to **30 m/s** (with 70 kg)
- (Sled deceleration: up to **300 g** in 15 ms)
- High-speed videos: more than **1000 fps HD**
- Precise testing and reproducibility due to guided sled

- Exemplary approach:
 - Quasi-static (1 mm/s) and dynamic (3000 mm/s) indentation tests with cylindrical impactor



Results: Dynamic vs. Quasi static testing

- Comparison of:
 - Failure deformation
 - Force increase
- Exemplary approach results dynamic compared to quasi-static:
 - Lower peak force
 - Lower failure displacement



- Many different boundary conditions and loadings change the battery behavior
 - ➔ In the laboratory, boundary conditions and loadings can be controlled and monitored
- Depending on the simulation parameter required, different types of test can be performed:
 - Thermal tests
 - Electric tests
 - Mechanical tests
- Further information can be gathered from post-mortem analysis or disassembly of cells not subjected to critical loadings
- Advanced test results are used for model validation (FEM, multi-physics, etc.) or calibration



**Vehicle Safety Institute – VSI
Graz University of Technology**

Inffeldgasse 23/I
8010 Graz, Austria
Website: www.vsi.tugraz.at

Emanuele Michelini
E-Mail: e.michelini@tugraz.at

Alexander Schmid
E-Mail: alexander.schmid@tugraz.at

Patrick Höschele
E-Mail: patrick.hoeschele@tugraz.at

Jörg Moser
E-Mail: joerg.moser@tugraz.at

Christian Ellersdorfer
E-Mail: christian.ellersdorfer@tugraz.at

Partners



Das COMET-Projekt SafeLIB wird im Rahmen von COMET – Competence Centers for Excellent Technologies durch BMK, BMDW, das Land Oberösterreich, das Land Steiermark sowie die SFG gefördert. Das Programm COMET wird durch die FFG abgewickelt.

The COMET Project SafeLIB is funded within the framework of COMET - Competence Centers for Excellent Technologies by BMK, BMDW, the Province of Upper Austria, the province of Styria as well as SFG. The COMET Programme is managed by FFG.

 **Bundesministerium**
Klimaschutz, Umwelt,
Energie, Mobilität,
Innovation und Technologie

 **Bundesministerium**
Digitalisierung und
Wirtschaftsstandort



COMET

Competence Centers for
Excellent Technologies

