# Multi-physical characterization and simulation of battery cells for predicting abuse scenarios

**Martin Schwab** 

Battery Day 2022





excellence in ...
plastics simulation
testing equipment
lightweight products






#### **Testing and Identification**























#### **Outline**


- 1. Generation of abuse simulation models of a single battery cell using LS Dyna
- 2. Abuse testing and simulation of a single battery cell
- 3. Application of a single cell model within the simulation of multi-cell mockups
- 4. Conclusion and outlook





# Generation of abuse simulation models of a single battery cell using LS Dyna


### **Multiphysics of battery cells**

















## Modeling approaches in LS DYNA

	Solid layer model	Tshell model	Batmac model
4CI			
Keyword	*EM_RANDLES_SOLID	*EM_RANDLES_TSHELL	*EM_RANDLES_BATMAC
Characteristics	<ul><li>+ Analysis of the different layers is possible</li><li>- Computational effort</li></ul>	<ul> <li>+ Benefical modeling of thin cells</li> <li>- Behavior of the layers can not be analyzed in detail</li> </ul>	<ul> <li>+ Modeling with respect to mechanical and thermal problem</li> <li>- Behavior of the layers can not be analyzed</li> </ul>




#### **Electrical modelling and characterization**


electrical behavior is covered by a circuit model









parameter as well as the OCV-SOC curve are identified from the 4a HPPC test











### Characteristic of the abuse of a battery cell

Course of voltage and temperature because of overheating







- Characteristic points and effects:
  - Internal short circuit: drop of the voltage
  - **Exothermic reaction**: spontaneous increase of the temperature




### Abuse simulation of a single cell

Modeling of the internal short circuit and the exothermal reaction







Initiation criterion:

$$\Phi_S\left(T, \text{SOC}, \underline{\underline{\varepsilon}}\right) \ge 1$$

Short resistance:

$$R = \text{const.}$$

**Internal short circuit** 

Initiation criterion:

$$\Phi_E(T) \ge 1$$


Additional heat source:

**Exothermal reaction** 



Abuse testing and simulation of a single battery cell

- Overheating of a fully charged 18650 battery cell (Panasonic NCR18650B) at the bottom
- Measurement of the temperature at the cell as well as in the chamber with 6 thermocouples
- Measurement of the voltage








18650 battery cell


fully charged overheating at bottom






#### Experimental results








I N



#### Comparison of experimental and simulative data










Application of a single cell model within the simulation of multi-cell mockups

#### Experimental investigation

- Thermal runaway of the center cell induced by heating with a heating wire
- Temperature and voltage measurement at each cell
- Video recording with high-speed camera








Experimental investigation

# Mock-up with seven 18650 battery cells

equal distances





Experimental investigation





Experimental investigation – behavior of all cells







<sup>\*</sup>Thermocouple at cell 6 was broken within the test



Experimental investigation – behavior of all cells






<sup>\*</sup>Thermocouple at cell 6 was broken within the test



### Experimental investigation – behavior of cell 1 and 2






#### Mockup with equal distances Simulation results

200

t in s

400







1500


1000

500

T in K

#### Experimental investigation

- Thermal runaway of the center cell induced by heating with a heating wire
- Temperature and voltage measurement at each cell
- Video recording with high-speed camera








Experimental investigation


## Mock-up with seven 18650 battery cells


different distances



### Experimental investigation – behavior of all cells












Experimental investigation – behavior of all cells











#### Mockup with different distances Simulation results





simulation experiment



— cell 1

— cell 2

<u>-</u> cell 4

<u>cell</u> 5


- cell 6

- cell 7

## Conclusion and outlook



#### Conclusion




#### Outlook

- Development of test setups for further characterizations of battery cells especially within the thermal runaway
- Automatic identification of the parameters required for the resulting FE model
- Optimization of battery packs addressing the thermal propagation behavior



#### Conclusion



#### Outlook

- Development of test setups for further characterizations of battery cells especially within the thermal runaway
- Automatic identification of the parameters required for the resulting FE model
- Optimization of battery packs addressing the thermal propagation behavior

Improve your developments with our expertise in testing and simulation!





Martin Schwab

martin.schwab@4a.at +43 (664) 80106 640



