



A new material model for continuous fiber reinforced plastics in crashworthiness analysis

Thomas Klöppel, Christian Liebold, André Haufe
DYNAmore GmbH



Agenda

- Motivation
- General Properties of Material *MAT_249_CRASH
- Damage and Failure Modelling in *MAT_249_CRASH
- Examples
- Summary



Motivation...

... to do something

- Project for material model development and implementation with
 - Dr. Michael Wrensch, Eric Chowson (Brose)
 - Dr. David Scheliga, Alexander Huf, Dr. Sebastian Schmeer (IVW, Uni KL)

- Goal: Material model for a composite with a woven reinforcement
 - Focus on thermoplastic matrix material
 - Pre-shearing of material during draping (thermoforming) should be considered
 - Considerable fiber shearing before material failure expected

Motivation...

... for a new material implementation

- Standard composite materials in LS-DYNA for crashworthiness are tailored for UD-reinforcements

Overview over Available Composite Models in LS-DYNA

	Element	Failure criteria	Rate dependency	Remarks
*MAT_022: COMPOSITE_DAMAGE	Shell, Tshell, Solid	Chang-Chang	-	ALPH doesn't affect stress vs. strain relationship. (same for 054/055)
*MAT_054/055: ENHANCED_COMPOSITE_DAMAGE	Shell, Tshell, Solid	54: Chang-Chang 55: fiber: as 54 matrix: Tsai-Wu	rate dependent strength via *DEFINE_CURVE	fiber strengths can be reduced after matrix failure. Minimum stress limit factor. Crash front algorithm.
*MAT_058: LAMINATED_COMPOSITE_FABRIC	Shell, Tshell (1,2,6), Solid	Modified Hashin	rate dependent Strengths and strains via *DEFINE_CURVE	Smooth increase of damage. Special control of shear behavior Minimum stress limit factor. Crash front algorithm.
*MAT_059: COMPOSITE_FAILURE_MODEL	Shell, Tshell, Solid, SPH		-	Similar to 054. Crash front algorithm. Minimum stress limit factor.
*MAT_158: RATE_SENSITIVE_COMPOSITE_FABRIC	Shell, Tshell	Modified Hashin	Viscosity based on isotropic viscoelasticity	Same as 058.
*MAT_261: LAMINATED_FRACTURE_DAIMLER_PINHO	Shell, Tshell, Solid	Pinho	rate (and element size) dependent strengths and fracture toughness via *DEFINE_CURVE/ _TABLE	Considers the state-of-the-art Puck's criterion for inter-fiber failure
*MAT_262: LAMINATED_FRACTURE_DAIMLER_CAMANHO	Shell, Tshell, Solid	Camanho	as *MAT_261	Considers the state-of-the-art Puck's criterion for inter-fiber failure

Motivation...

... for a new material implementation

- Standard composite materials in LS-DYNA for crashworthiness are tailored for UD-reinforcements

***MAT_LAMINATED_COMPOSITE_FABRIC (*MAT_058) – Failure**

Failure mode	FS=0.0	FS=1.0	FS=-1.0
<p>Tensile fiber mode</p>	$e_m^2 = \left(\frac{\sigma_{11}}{X_T}\right)^2 - 1$	<p>Failure is assumed whenever $e_m^2 > 0$</p> $e_m^2 = \left(\frac{\sigma_{11}}{X_T}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	$e_m^2 = \left(\frac{\sigma_{11}}{X_T}\right)^2 - 1$
<p>Compressive fiber mode</p>	$e_d^2 = \left(\frac{\sigma_{11}}{X_C}\right)^2 - 1$	<p>Failure is assumed whenever $e_d^2 > 0$</p> $e_d^2 = \left(\frac{\sigma_{11}}{X_C}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	$e_d^2 = \left(\frac{\sigma_{11}}{X_C}\right)^2 - 1$
<p>Tensile matrix mode</p>	$\varepsilon_m^2 = \left(\frac{\sigma_{22}}{Y_T}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	<p>Failure is assumed whenever $\varepsilon_m^2 > 0$</p> $\varepsilon_m^2 = \left(\frac{\sigma_{22}}{Y_T}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	$\varepsilon_m^2 = \left(\frac{\sigma_{22}}{Y_T}\right)^2 - 1$
<p>Compressive matrix mode</p>	$\varepsilon_d^2 = \left(\frac{\sigma_{22}}{Y_C}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	<p>Failure is assumed whenever $\varepsilon_d^2 > 0$</p> $\varepsilon_d^2 = \left(\frac{\sigma_{22}}{Y_C}\right)^2 + \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$	$\varepsilon_d^2 = \left(\frac{\sigma_{22}}{Y_C}\right)^2 - 1$
			<p>Failure if $\varepsilon_s^2 > 0$</p> $\varepsilon_s^2 = \left(\frac{\sigma_{12}}{S_C}\right)^2 - 1$


Motivation...

... for a new material implementation

- Materials for woven structures focus on dry fabrics and/or draping behavior


*MAT_VISCOELASTIC_LOOSE_FABRIC (*MAT_234)

- micro-mechanical approach
- assumes symmetric woven fabric and



*MAT_MICROMECHANICS_DRY_FABRIC


- locking angle accounted for by a reduced
- assumes symmetric woven fabric



Basis for a new material model

*MAT_REINFORCED_THERMOPLASTIC (*MAT_249)


	1	2	3	4	5	6	7	8
Card 1	MID	RO	EM	LCEM	PRM	LCPRM	LCSIGY	BETA
Card 2	NFIB	AOPT	XP	YP	ZP	A1	A2	A3
Card 3	V1	V2	V3	D1	D2	D3	MANGLE	THICK
Card 4	IDF1	ALPH1	EF1	LCF1	G23_1	G31_1		
Card 5	G12	LCG12	ALOC12	GLOC12	METH12			
Card 6	IDF2	ALPH2	EF2	LCF2	G23_2	G31_2		
Card 7	G23	LCG23	ALOC23	GLOC23	METH23			
Card 8	IDF3	ALPH3	EF3	LCF3	G23_3	G31_3		
Opt C	POSTV							



- up to three fiber families can be accounted for
- non-linear hyper-elastic material formulation for each family
 - internally, a fiber is represented by a vector
 - deformation gradient provides necessary information to compute current orientation and strain of the fiber
- anisotropic transverse shear properties can be defined

*MAT_249_CRASH: General properties

Input, coupling approaches, elastic-plastic behavior, ...



*MAT_249_CRASH: General properties

Input

- Full name: *MAT_REINFORCED_THERMOPLASTIC_CRASH

- Keyword input:

- Matrix input
- Material coordinate system
- Fiber contributions
- Damage and failure

	1	2	3	4	5	6	7	8
Card 1	MID	RO	EM	PRM	LCSIGY	BETA	PFL	VISC
Card 2	NFIB	AOPT	XP	YP	ZP	A1	A2	A3
Card 3	V1	V2	V3	D1	D2	D3	MANGLE	THICK
ViscCard	VG1	VB1	VG2	VB2	VG3	VB3	VG4	VB4
Card 5	IDF1	ALPH1	EF1	LCF1	G23_1	G31_1	DAMF1	DAMM1
Card 6	G12	LCG12	ALOC12	GLOC12	METH12	DAMM12		
Card 7	IDF2	ALPH2	EF2	LCF2	G23_2	G31_2	DAMF2	DAMM2
Card 8	G23	LCG23	ALOC23	GLOC23	METH23	DAMM23		
Card 9	IDF3	ALPH3	EF3	LCF3	G23_3	G31_3	DAMF3	DAMM3
Opt C	POSTV	VISCS	IHIS					



- Additive split between
 - Isotropic, elastic-plastic matrix
 - Anisotropic, hyper-elastic fibers

*MAT_249_CRASH: General properties

Elastic-plastic properties of matrix

- Isotropic and hypo-elastic formulation
- Von Mises plasticity
 - Tabular data for yield stress
 - Flow curves
 - Strain rate dependency
- Strain hardening algorithm
 - Kinematic
 - Isotropic
 - Mixed strain hardening

Response to cyclic loading



*MAT_249_CRASH: General properties



Hyper-elastic fiber formulation

- Up to three fiber families can be accounted for
 - Internally represented by vectors
 - Based on deformation gradient, current orientation and strain of each family is computed

- Fiber stretch and compression
 - Tabular input for non-linear strain-stress response
 - Transverse shear stiffness in fiber direction can be defined

- Shear stress response
 - Based on reorientation of neighboring fiber families
 - Locking (shear or fiber) angle can be defined
 - Tabular input for non-linear elastic or elastic-plastic response

Response to shear loading



*MAT_249_CRASH: General properties


Hyper-elastic fiber formulation

- Up to three fiber families can be accounted for
 - Internally represented by vectors
 - Based on deformation gradient, current orientation and strain of each family is computed

- Fiber stretch and compression
 - Tabular input for non-linear strain-stress response
 - Transverse shear stiffness in fiber direction can be defined

- Shear stress response
 - Based on reorientation of neighboring fiber families
 - Locking (shear or fiber) angle can be defined
 - Tabular input for non-linear elastic or elastic-plastic response

Response to cyclic shear loading




*MAT_249_CRASH: General properties


Material characterization: In-plane shear behavior

- Cyclic loading to separate the effects


LS matrix only, kin. hardening




matrix only, isotr. hardening



6- fiber only



LS-DYNA keyword deck by LS-PrePost



*MAT_249_CRASH: General properties


Advanced data output and fiber definition

- Output control
 - Parameter POSTV defines additional history variables for post-processing
 - Additional data are written to the list prior to the algorithmic history variables
- Element-wise fiber orientation definition
 - Parameter IHIS defines how history data in *INITIAL_HISTORY_SHELL are interpreted
 - Fiber orientations with respect to global or material coordinate system possible

```


*MAT_REINFORCED_THERMOPLASTIC
Mat_1
$#   mid      ro      em      lcem      prm      lcprm      lcsigy      beta
     1  1.130E-6  20.0      0         0.3       0         0         0.0
$#   nfib     aopt     xp      yp      zp      al      a2      a3
     1      2.0      0.0      0.0     0.0      1.0     0.0     0.0
...
$#   postv    ihis
     8        1
*INITIAL_STRESS_SHELL
$   eid  nplane  nthick  nhisv  ntensr  large  nthint  nthhisv
     1    1      1        7       0       0       0
$   t    sigxx  sigyy  sigzz  sigxy  sigyz  sigzx  eps
0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00
$#-----1|-----2|-----3|-----4|-----5|-----6|-----7|
0.000e+00 0.000e+00 0.000e+00 0.000e+00 1.000e+00 1.000e+00 0.000e+00
$   eid  nplane  nthick  nhisv  ntensr  large  nthint  nthhisv
     2    1      1        7       0       0       0
$   t    sigxx  sigyy  sigzz  sigxy  sigyz  sigzx  eps
0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00 0.000e+00
$#-----1|-----2|-----3|-----4|-----5|-----6|-----7|
0.000e+00 0.000e+00 0.000e+00 0.000e+00 1.000e+00 -1.000e+00 0.000e+00

```



*MAT_249_CRASH: Damage and Failure

Basic concept, fiber and matrix softening algorithms, ...



*MAT_249_CRASH: Damage and Failure

A phenomenological approach

Damage and failure

- Tabular input data relating fiber state to several softening mechanisms
 - Fiber length change damage fiber and matrix
 - Individual softening parameters for fiber stretch and compression
 - Reorientation of fibers induces softening in the matrix

- Matrix deformation cannot trigger damage or failure

- Artificial fiber viscosity can be defined to avoid snapback of elements in the vicinity of a crack

	1	2	3	4	5	6	7	8
Card 1	MID	RO	EM	PRM	LCSIGY	BETA	PFL	VISC
Card 2	NFIB	AOPT	XP	YP	ZP	A1	A2	A3
Card 3	V1	V2	V3	D1	D2	D3	MANGLE	THICK
ViscCard	VG1	VB1	VG2	VB2	VG3	VB3	VG4	VB4
Card 5	IDF1	ALPH1	EF1	LCF1	G23_1	G31_1	DAMF1	DAMM1
Card 6	G12	LCG12	ALOC12	GLOC12	METH12	DAMM12		
Card 7	IDF2	ALPH2	EF2	LCF2	G23_2	G31_2	DAMF2	DAMM2
Card 8	G23	LCG23	ALOC23	GLOC23	METH23	DAMM23		
Card 9	IDF3	ALPH3	EF3	LCF3	G23_3	G31_3	DAMF3	DAMM3
Opt C	POSTV	VISCS	IHIS					

*MAT_249_CRASH: Damage and Failure

Fiber softening algorithms

- Tabular data input
 - Define softening parameter d_i^f vs. fiber strain λ_i

$$\hat{\sigma}_T^f = \sum_i (1 - d_i^f(\lambda_i)) \sigma_{T_i}^f$$

- Softening of tensile and compressive stresses can be considered individually

$$d_i^{f,c}(t^n, \lambda_i) = \max(d_i^{f,c}(t^{n-1}, \lambda_i), \text{DAMC}_i(\lambda_i))$$


$$d_i^{f,t}(t^n, \lambda_i) = \max(d_i^{f,t}(t^{n-1}, \lambda_i), \text{DAMT}_i(\lambda_i))$$

- Fiber damage of fiber i is defined as

$$d_i^f(\lambda_i) = \begin{cases} d_i^{f,c}, & \lambda_i < 0 \\ d_i^{f,t}, & \lambda_i \geq 0 \end{cases}$$

- Integration point fails if all fibers are completely damaged, i.e. $\min_i d_i^f = 1$.

One element, uniaxial test



*MAT_249_CRASH: Damage and Failure




Matrix softening mechanisms

- Matrix is damaged if fibers are shortened or elongated
 - Tabular input data (softening vs. fiber strain)
 - Strain rate effects can be accounted for

- Matrix is damaged if fibers reorient
 - Tabular input data (softening vs. shear angle of neighboring fibers)


- A fully damaged matrix not necessarily triggers failure of an integration point
 - Failure is initiated if softening parameter exceeds 1.5
 - Naturally, stress softening is limited to 1.0

Uniaxial tensile test in fiber direction



Examples



Proof of concept



Ex 1: Three-point bending of a hat-profile






Comparison of an NCF and a woven reinforcement



Ex 1: Three-point bending of a hat-profile

Comparison of an NCF and a woven reinforcement





Ex 2: Impact example

Set-up

- Based on validation example from the EXTREME project
 - The aim of the EXTREME project is to develop novel material characterization methods and in-situ measurement techniques, material models and simulation methods for the design and manufacture of aerospace composite structures under EXTREME dynamic loadings.

Th
an

D7.5 Design of validation structure




	Test#1
Substitute Bird test speed	150 knots = 77.0 m/sec
Substitute Bird mass	2 lb = 0.91 kg
Substitute Bird diameter	85.0 mm
Substitute Bird length	170.0 mm
Temperature	Ambient
Impact location	See Figure

mean Uni
49.

Simplified model

- Geometry
- Shell model
- Constant thickness (3.2mm)
- Same lay-up everywhere




Ex 2: Impact example


Results for quasi-isotropic composite




Time = 0



Time = 0
Contours of History Variable#20
shell integration pt#1
max=0, at node# 85490







History Variable#20



contours of matrix damage

Ex 2: Impact example

Results for different simple composites with woven reinforcements




base orientation
→

Summary

- Discussed new material model *MAT_249_CRASH
 - Additive split between an isotropic, elastic-plastic matrix and anisotropic, hyper-elastic fibers
 - Phenomenological description of damage and failure
 - Damage due to fiber elongation and compression considered individually
- Showed some applications
 - Pre-shearing of material from draping (thermoforming) can be considered
 - Fiber shearing before material failure can occur
 - Applicable to woven textiles, UD layers and NCFs
- Calibration of the model successfully completed in the project with Brose and the IVW

Thank You



DYNAmore GmbH
Industriestr. 2
70565 Stuttgart-Vaihingen
Germany

Tel.: +49 - (0)711 - 459 600 0
Fax: +49 - (0)711 - 459 600 29
info@dynamore.de

www.dynamore.de
www.dynaexamples.com
www.dynasupport.com
www.dynalook.com

© 2022 DYNAmore GmbH. All rights reserved.
Reproduction, distribution, publication or display of the slides and content
without prior written permission of the DYNAmore GmbH is strictly prohibited.

Find us on



DYNAmore worldwide
Germany ■ France ■ Italy ■ Sweden ■ Switzerland ■ USA