

DynaXtend - Flexible And Short-Term LS-DYNA Software and Hardware Lease

Maik Schenke, DYNAmore GmbH
Christian Engfer, T-Systems

Stuttgart, 28 March 2022

What is DynaXtend

■ Special LS-DYNA Model from DYNAmore


- Short-term LS-DYNA leasing
- Booking at short-notice
- Optional hardware lease

→ Boosting you simulation capacity at short-noticed

■ Beneficial for e. g.

- Peaks in simulation demands
- Short-term projects
- Hardware failures

■ High-Performance Cloud Computing in cooperation with T-Systems and the High-Performance Computing Center (HPCC) Stuttgart



High-Performance Computing


- Hawk (HPE Apollo 6500 Gen10 Plus)
(<https://www.hirs.de/systems/hpe-apollo-hawk/>)
 - AMD EPYC™ 7742 CPU @ 2.25 GHz
 - 5632 nodes with 128 cores per node
 - 192 NVIDIA A100 GPU
 - ~ 1.44 PB of memory
 - ~ 25 PB of disk space
- Performance
 - Ranked 24 in world-wide top 500 list
(<https://www.top500.org/lists/top500/list/2021/11/>)
- Very good parallel scaling with LS-DYNA



Access, booking, prices

- Currently, provides independent software and hardware lease
 - LS-DYNA license from DYNAmore
 - Machine lease via your hardware provider of choice, e. g.
 - Ansys Cloud Asure
 - T-Systems PLM Cloud
 - Gompute Cloud
- Tight cooperation with T-Systems PLM Cloud
 - Easy access via web interface or drag and drop folders on your local hardware
 - Different hardwares to choose from, e. g. 128-Core node at Hawk
- DynaXtend
 - Monthly lease
 - Daily booking
 - Prices and contact for **LS-DYNA licenses**, see <https://www.dynamore.de/de/produkte/dynaxtend>
 - Booking for **PLM Cloud contact** karl-heinz.hierholz@t-systems.com

HPC Access via T-Systems PLM Cloud




T LIFE IS FOR SHARING.

TISAX
ENX ASSOCIATION

¹Product life-cycle management: synonymous for engineering cloud

HPC Access via T-Systems PLM Cloud

- **TISAX¹** approved
- Three options to submit a job
 - 1 **Virtual Desktop Infrastructure (VDI)**
Direct access compute hardware via a virtual desktop via **HDP**
 - 2 **Web submit**
Upload and download of input decks and result files, respectively, via web interface via **HTTPS**
 - 3 **Drag and Drop**
predefined folders on your local machine are kept in sync with compute hardware via **VPN**
 - All **Outbox** files will be sent to compute hardware
 - All **Inbox** files will be retrieved from compute hardware



Regardless of the option, the compute-job progress can always be tracked via web interface

¹TISAX (Trusted Information Security Assessment Exchange) is a standard for information security management system in the automobile industry

HPC Access via T-Systems PLM Cloud

■ Three possibilities for LS-DYNA licensing

a e-licensing

Open licensing server connected to computer hardware via URL


b Customer

License server at customers premise will be connected via VPN to compute hardware. **Requires LS-DYNA license to cover IP range of compute hardware.**

c Cloud-license server

Customer license server runs PLM Cloud

preferred for LS-DYNA licensing through DynaXtend



HPC Access via T-Systems PLM Cloud

- Submitting a job via **Web submit** comprises
 - LS-DYNA input deck (as archive)
 - Job control file (.control)
- LS-DYNA input deck
 - Conveniently as compressed as an archive

| Name | Date modified | Type | Size |
|---------------------------------|------------------|------------------------|-------|
| Electricmotor.cn25l,hhe.control | 09.03.2022 14:39 | CONTROL File | 8 KB |
| Electricmotor.zip | 09.03.2022 14:39 | Compressed (zipped...) | 79 KB |

| | | | |
|-------------------|-------------|------|-------------|
| cntl | File folder | | |
| contact | File folder | | |
| cs | File folder | | |
| db | File folder | | |
| initvel | File folder | | |
| mat | File folder | | |
| model | File folder | | |
| Electricmotor.dyn | DYN File | 1 KB | No 1 KB 52% |

HPC Access via T-Systems PLM Cloud

■ Job control file (.control) defining, e. g.,

- subSolver defines solver, e. g. lsdyna
- subSolverVersion defines solver version
- subInputFile defines LS-DYNA master file
- subOutputFileList defines list of result files to be compressed and send back
- subReqNodeFlavor defines hardware which to use, e. g. CN25 for Hawk. A complete list of available hardware can be found here (<https://cloud.telekom.de/en/infrastructure/plm-cloud>) under *Service description*
- subReqNodeNumber defines number of nodes
- subReqMaxWallTime defines hard limit of job runtime. Once limit is reached job will be terminated

```
# -----
# The evaluated block of this file is marked by a subControlBegin and a subControlEnd line
# In this block informations are provided in the format: keyword:"value"
# - Keyword must start in the 1st column
# - Keyword must be followed by a colon immediately without blanks
# - Value must follow the colon immediately without blanks and must be quoted
#####

subControlBegin

#####
# Mandatory parameters
#####

# -----
# Solver and SolverVersion
# - "ansyscfx": "v211"
# - "lsdyna": "mpp_s_r9_3_1_sharelib", "mpp_s_r9_3_1"
# - "permas": "V_17.00.275_LINUX_X86_IFORT12_S64"
# - "starccmp": "15.06.007", "15.06.007-R8"
# -----

subSolver:"lsdyna"
subSolverVersion:"mpp_s_r9_3_1"
```

- subJobName defines a jobname
- subProject defines projectname, which is useful for tracking of resources and accounting
- subResultCompress defines the compression method of the result files before copied
- subOutputWatchFileList defines list of files to be watched while job is running



ERLEBEN, WAS VERBINDET.

BUSINESS LOGIN

Bitte melden Sie sich an

[Benutzername vergessen?](#) [Passwort vergessen oder abgelaufen?](#)

[Brauchen Sie Hilfe?](#)




Let's power higher performance



Drop your job here

| <input type="checkbox"/> | jobid | gstcsoid | l1status | l3status | lastregularl3sta... | userid | jobname | inputfile | project | flavor | nodenu... | corenu... | sol | Actions |
|--------------------------|---|---|---------------------------------------|---------------------------------------|---------------------------------------|--|--|--|---|--|--------------------------------|----------------------------------|-----------------------------------|---|
| <input type="checkbox"/> | <input type="text" value="w1f4add6590ba2c95900"/> | <input type="text" value="8400000601"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="k50193689"/> | <input type="text" value="Electricmotor01"/> | <input type="text" value="Electricmotor.dyn"/> | <input type="text" value="Projectname"/> | <input type="text" value="cn25l.hhe"/> | <input type="text" value="1"/> | <input type="text" value="128"/> | <input type="text" value="lscd"/> | <input type="button" value="submit.log"/> 2 |
| <input type="checkbox"/> | <input type="text" value="w1f4add6590ba1aa3400"/> | <input type="text" value="8400000601"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="k50193689"/> | <input type="text" value="Electricmotor01"/> | <input type="text" value="Electricmotor.dyn"/> | <input type="text" value="Projectname"/> | <input type="text" value="cn25l.hhe"/> | <input type="text" value="1"/> | <input type="text" value="128"/> | <input type="text" value="lscd"/> | <input type="button" value="submit.log"/> 2 |
| <input type="checkbox"/> | <input type="text" value="w1f4add6590b9c6a7d00"/> | <input type="text" value="8400000601"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="k50193689"/> | <input type="text" value="cavity_500x500_tmax-0.5_dt-0.00002_1n"/> | <input type="text" value="cavity.sh"/> | <input type="text" value="TSITestProject"/> | <input type="text" value="cn25l.hhe"/> | <input type="text" value="1"/> | <input type="text" value="128"/> | <input type="text" value="op"/> | <input type="button" value="submit.log"/> 2 |
| <input type="checkbox"/> | <input type="text" value="w1f4add6590b9c69f600"/> | <input type="text" value="8400000601"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="FINISHED"/> | <input type="text" value="k50193689"/> | <input type="text" value="Electricmotor01"/> | <input type="text" value="Electricmotor.dyn"/> | <input type="text" value="Projectname"/> | <input type="text" value="cn25l.hhe"/> | <input type="text" value="1"/> | <input type="text" value="128"/> | <input type="text" value="lscd"/> | <input type="button" value="submit.log"/> 2 |



Summary

- DynaXtend is flexible LS-DYNA licensing approach to cope with peaks in simulation demands
- Optionally, can be combined with hardware lease with your hardware provider of choice, e. g.
 - Ansys Cloud Asure
 - T-Systems PLM Cloud
 - Gompute Cloud
- Access to HPC, e. g. Hawk at HPC Stuttgart
- In case of PLM Cloud, access via
 - VDI
 - Web interface
 - Drag-and-drop folders on your local machine
- Pricing can be found at <https://www.dynamore.de/en/products/dynaxtend>
- Booking via kathleen.fritz@dynamore.de

More Information on our Product Suite

- **LS-DYNA**


- Support / Tutorials / Examples / FAQ
www.dynasupport.com
- More Examples
www.dynaexamples.com
- Conference Papers
www.dynalook.com
- European Master Distributor
www.dynamore.de

- **LS-PrePost**

- Support / Tutorials / Download
www.lstc.com/lsp

- **LS-OPT**

- Support / Tutorials / Examples
www.lsoptsupport.com



[THUMS® www.dynamore.de]



Your questions, please