

DREIDIMENSIONALE, KONTINUUMSMECHANISCHE MODELLIERUNG DES MUSKULOSKELETALEN APPARATES



Oliver Röhrle, Michael Sprenger

Email: roehrle@simtech.uni-stuttgart.de



OVERVIEW

- **Motivation**
 - Different skeletal muscle modelling approaches
 - Overview on forward-dynamics and inverse-dynamics musculoskeletal modelling approaches
 - Shortcomings
- **Modelling framework of a two-muscle model upper limb model**
 - Geometrical Model
 - Continuum-mechanical skeletal muscle model
 - Solving the musculoskeletal system
- **Simulation results**
 - Convergence studies
 - Contact forces acting within the system
- **Outlook**

Motivation

Modelling


Simulation

Outlook




BASIC PRINCIPLES OF FORWARD / INVERSE DYNAMICS

- Forward / inverse dynamics musculoskeletal modelling




- Motivation
- Modelling
- Simulation
- Outlook



THE MUSCULOSKELETAL SYSTEM

- There exist many different approaches to model the mechanical behavior of skeletal muscle:
 - Biophysical Huxley-type models (including the neuromuscular system)
 - (Chemo-)Electro-mechanical skeletal muscle models
 - Continuum-mechanical skeletal muscle models
 - Hill-type skeletal muscle models
- Modelling the musculoskeletal system:
 - Inverse dynamics models
 - Forward dynamics models
- State-of-the-art musculoskeletal system models:
 - Inverse dynamics models using Hill-type skeletal muscle models



Forward dynamics simulations courtesy of JP Syn Schmitt,
Institut für Sport- und Bewegungswissenschaft, Universität Stuttgart




LIMITATIONS OF EXISTING MUSCULOSKELETAL MODELS

- Limitations of the state-of-the-art models:
 - Hill-type skeletal muscle models are lumped-parameter discrete models that have difficulties to take into account any spatial characteristics of skeletal muscles.
 - They cannot take into account any contact between skeletal muscles and surrounding structures.

⇒ **Three-dimensional, continuum-mechanical skeletal muscle models**

- Challenges of continuum-mechanical models:
 - Continuum-mechanical models of musculoskeletal systems are rare:
 - Only a few inverse-dynamics approaches exist
 - Forward-dynamics frameworks do not exist
 - Computational expensive
 - Convergence due to the force-length relationship




- Motivation
- Modelling
- Simulation
- Outlook



THE UPPER LIMB MODEL


- Model components from Visible Human Project



- Motivation
- Modelling**
- Simulation
- Outlook



THE UPPER LIMB MODEL



Introducing the equivalent static system

- Muscle length is modelled as the distance between muscle origin and insertion
- Formulating the momentum balance in the elbow joint:

$$T(\theta, \alpha_T) l_T(\theta) + F l_F(\theta) - B(\theta, \alpha_B) l_B(\theta) = 0$$


- Initially, the lever arms are determined using the tendon displacement method or using the actual geometry of the system
- Muscle forces are determined by FEM simulations using the continuum mechanical muscle approach



CONTINUUM-MECHANICAL CONSTITUTIVE EQUATIONS


- Continuum-mechanical models describe the mechanics of the muscle and surrounding tissue.
- Assumptions on skeletal muscles model:
 - Hyperelastic, incompressible, transversely isotropic
 - Stress-strain relation (constitutive equation)

$$\mathbf{S}_{MTC} = \mathbf{S}_{iso} + \mathbf{S}_{aniso} = \mathbf{S}_{iso} + (\mathbf{S}_{passive} + \alpha \gamma_M \mathbf{S}_{active}) (1 - \gamma_{ST})$$




tissue	contribution	parameter	triceps	biceps	source	
muscle	isotropic	c_{1M}	$3.56 \cdot 10^{-2}$ MPa	$3.56 \cdot 10^{-2}$ MPa	[HaBe1994]	
		c_{2M}	$3.86 \cdot 10^{-3}$ MPa	$3.86 \cdot 10^{-3}$ MPa		
	passive	c_{3M}	$4.02 \cdot 10^{-7}$ MPa	$3.57 \cdot 10^{-8}$ MPa	[Zhen1999]	
		c_{4M}	38.5 [-]	42.6 [-]		
	active	ΔW_{asc}		0.30 [-]	0.25 [-]	adapted from [Gunt2007]
		ΔW_{desc}		0.10 [-]	0.15 [-]	
		ν_{asc}		4.00 [-]	3.00 [-]	
ν_{desc}			4.00 [-]	4.00 [-]		
		λ_f^{opt}	1.3 [-]	1.35 [-]	-	
		σ_{max}	0.30 MPa	0.30 MPa	-	
tendon	isotropic	c_{1T}	2.31 MPa	2.31 MPa	WeGa2001]	
		c_{2T}	$1.15 \cdot 10^{-6}$ MPa	$1.15 \cdot 10^{-6}$ MPa		
	passive	c_{3T}	7.99 MPa	7.99 MPa	[WeGa2001]	
		c_{4T}	16.6 [-]	16.6 [-]		


- Motivation
- Modelling
- Simulation
- Outlook



CONTINUUM-MECHANICAL CONSTITUTIVE LAW




Force-length relationship



Force-velocity relationship

- Motivation
- Modelling
- Simulation
- Outlook



SOLVING THE EQUILIBRIUM EQUATIONS

Challenge: Solve the equilibrium equations using the muscle forces stemming from the 3D, continuum-mechanical tissue models:

$$T(\theta, \alpha_T) l_T(\theta) + F l_F(\theta) - B(\theta, \alpha_B) l_B(\theta) = 0$$

- Position-driven scenario (activation for a particular elbow position / “inverse model”)


$$\alpha_T^{(i+1)} = \alpha_T^{(i)} - \frac{M^{(i)}}{\frac{\partial M^{(i)}}{\partial \alpha_T}}, \quad i=1, \dots, n, \quad \text{with} \quad \frac{\partial M^{(i)}}{\partial \alpha_T} \approx \frac{\Delta M^{(i)}}{\Delta \alpha_T^{(i)}} = \frac{M^{(i)} - M^{(i-1)}}{\alpha_T^{(i)} - \alpha_T^{(i-1)}} = \frac{T^{(i)} - T^{(i-1)}}{\alpha_T^{(i)} - \alpha_T^{(i-1)}}$$

- Activation-driven scenario (elbow angle for a prescribed activation / “forward model”):


$$\theta^{(i+1)} = \theta^{(i)} - \frac{M^{(i)}}{\frac{\partial M^{(i)}}{\partial \theta}}, \quad i=1, \dots, n, \quad \text{with} \quad \frac{\partial M^{(i)}}{\partial \theta} \approx \frac{\Delta M^{(i)}}{\Delta \theta^{(i)}} = \frac{M^{(i)} - M^{(i-1)}}{\theta^{(i)} - \theta^{(i-1)}}$$

- Force-driven scenario can be described in a similar way.

- Motivation
- Modelling
- Simulation
- Outlook



SKELETAL MUSCLES AS ISOLATED SIMULATIONS





- Investigating for the full range of motion, i.e.,
 - Motion [$10 \leq \theta \leq 150$], activation [$0 \leq \alpha \leq 1$], with/ without contact
- The impact on:
 - Reaction forces' magnitude and orientation
 - Fibre stretch and resulting muscle shapes
 - Impact of muscle-bone interaction

- Motivation
- Modelling
- Simulation
- Outlook




MUSCLE AND CONTACT FORCES


- Muscle forces for the full range of motion and different levels of activation (left) and the contact reaction forces (right) for full activation of the biceps and the triceps muscle.



- Motivation
- Modelling
- Simulation
- Outlook



IMPACT OF CONTACT ON MUSCLE FIBRE DISTRIBUTION




(a) fully extended,
 $\theta = 10^\circ$, and $\alpha = 0$

(b) fully extended,
 $\theta = 10^\circ$, and $\alpha = 1$

(c) fully flexed,
 $\theta = 150^\circ$, and $\alpha = 0$


(d) fully flexed,
 $\theta = 150^\circ$, and $\alpha = 1$

- Motivation
- Modelling
- Simulation
- Outlook



POSITION-DRIVEN SCENARIO

- By assuming variations in activation, one can achieve „forward dynamics“ simulation, hence
 - with $\bar{\alpha}_T = 0.09$, $\bar{F} = 44 \text{ N}$ and
 - $\alpha_B(t_1) = 88.58\% \rightarrow \theta_{equi} = 57.47^\circ$
 - $\alpha_B(t_2) = 32\% \rightarrow \theta_{equi} = 38.27^\circ$
 - $\alpha_B(t_3) = 65\% \rightarrow \theta_{equi} = 50.10^\circ$




- Motivation
- Modelling
- Simulation
- Outlook



USER MATERIAL IMPLEMENTATION IN LS-DYNA

LS-DYNA keyword deck by LS-PrePost

Muscle model




- Motivation
- Modelling
- Simulation
- Outlook




A DISPLACEMENT-DRIVEN SCENARIO

LS-DYNA keyword deck by LS-PrePost
Time = 0
Contours of X-strain-Green St Venant
min=-6.19888e-06, at elem# 4405
max=5.72205e-06, at elem# 3670





- Motivation
- Modelling
- Simulation
- Outlook




A FORCE-DRIVEN SCENARIO

LS-DYNA keyword deck by LS-PrePost
Time = 0
Contours of X-stress
min=-3.24914e-07, at elem# 4164
max=1.13872e-06, at elem# 3555





- Motivation
- Modelling
- Simulation
- Outlook



FULL UPPER ARM MODEL

- Implicit dynamic simulation of an upper arm motion
 - The muscle, muscle-tendon and tendon behavior are modelled with the proposed constitutive law
 - All bones are assumed to be rigid
 - The biceps is assumed to be fusiform.
 - The triceps is assumed to be bipennate.
 - Both muscles are fully activated within the first second of the motion






VALIDATION – HIGH DENSITY EMG

- Part of the Fraunhofer MAVO – EMMA-CC we aim to
 - Look at research questions arising in ergonomics
 - Use HD-EMG data to determine muscular activation
 - Use Motion Capture analysis techniques to determine movement





- Motivation
- Modelling
- Simulation
- Outlook




DETAILED CHEMO-ELECTRO-MECHANICAL MODELS

- Motivation
- Modelling
- Simulation
- Outlook





Stimulation protocol defining $I_{stim}(t)$ at the nodal locations of the neuromuscular junctions.

O. Röhrle, "Simulating the Electro-Mechanical Behavior of Skeletal Muscles", IEEE Computing in Science and Engineering, DOI 10.1109/MCSE.2010.30



OUTLOOK

- **Extension to a multiple muscle scenario**
 - Contact between multiple muscles
 - Control strategies for multiple muscles? Solving the forward problem
 - Extension to chemo-electro-mechanical skeletal muscle models and biophysical based neuromuscular models for muscle recruitment
 - Couple continuum-mechanical models with Hill-type modelling approaches like the forward-Inverse-dynamics model (Bezier, Lloyd,...) to drive the model (predictor-corrector)
 - Model order reduction for muscles
- **Moment arm calculation**
 - Currently, the common (analytical) method of An (1992) is used. However, due to the knowledge of the muscle force directions and the resulting geometry, accurate moment arms can be computed
- **Validation**
 - Biodex experiments for moment arms
 - Linking experimentally determined EMG data to drive the model and validate motion.



THANK YOU!



European Research Council
Established by the European Commission

This research has received funding from the European Research Council under the European Union's Seventh Framework Programme (FP7/2007-2013) / ERC Grant n 306757 and from the Cluster of Excellence for Simulation Technology (SimTech), DFG ExC 310.