

Benefits of the Mapping Tool ENVYO for Simulation of Braided Composites

Information day ENVYO

M. Vinot

German Aerospace Center (DLR)
Institut of Structures and Design
Stuttgart



Wissen für Morgen



Content

1. The research campus ARENA2036 and the project DigitPro
2. Generating the finite-element model of a braided tube on the mesoscale
3. Mapping meso-macro with ENVYO for the structure simulation
4. Conclusion and future perspective



The research campus ARENA2036

Active Research Environment for the Next generation of Automobiles

- Developing the industry 4.0 with increased flexibility and reduced energy needs
- 3 research fields + 1 transverse research field

LeiFu

Material and design


- Lightweight materials
- Function integration



DigitPro

Digital Prototype

- Process simulations
- Virtual testing



ForschFab


Research factory

- manufacturing processes of the future



Khoch3 (transversal research field)

Creativity – Cooperation – Competences



ARENA2036 research factory in S-Vaihingen



DigitPro – Digital Prototype



- closed, numerical process chain
- from the presizing up to the final product
- modelling on meso- and macroscales
- various simulation tools
- HDF5 format

Investigated textile fibre architectures

– Braided composites



– **Open-Reed-Weaving**



Process chain at the example of a braided structure



Content


1. The research campus ARENA2036 and the project DigitPro
- 2. Generating the finite-element model of a braided tube on the mesoscale**
3. Mapping meso-macro with ENVYO for the structure simulation
4. Conclusion and future perspective



Investigation of braided structures - methodology

Reference approach

Modelling with UD-plyies



Advantages

- „universal“ approach (weave / UD...)
- fast model generation
- low computing time

Drawbacks

- local effects are not considered
- fibre architecture is not reproduced

Mapping approach

1. Generation of a realistic FE-Model on the mesoscale
2. Transfer of yarn orientations on a target mesh



Advantages



- realistic approach
- consideration of manufacturing effects

Drawbacks

- complex model generation
- increased computing time




Generation of a Representative Volume Element - RVE



- Material-database for the mechanical properties of braids
- RVE as a basis for detailed investigations
- Geometry as a basis for the generation of more complex parts



Generation of a mesoscopic tube model



Content


1. The research campus ARENA2036 and the project DigitPro
2. Generating the finite-element model of a braided tube on the mesoscale
- 3. Mapping meso-macro with ENVYO for the structure simulation**
4. Conclusion and future perspective





The mapping algorithmus ENVYO

Principle of the algorithmus


- Mapping of yarns orientations on a target mesh
- Beam-on-shells or shells-on-shells
- Possibility to map resin-rich zones





Investigation of the mapping tool ENVYO – crushing test on triaxial braid 30°



- Each layer is represented by a shell element
- Use of cohesive contact between the layers
 - CONTACT_SURFACE_TO_SURFACE_TIEBREAK, OPT = 8




Results of the numerical crushing test



- The mapping approach renders more realistically the braids failure modes.
- The computing time is slightly increased (5% longer by same element length in reference and mapped model) due to the use of *ELEMENT_SHELL_COMPOSITE_BETA



Results of the numerical crushing test



- Reduced tube stiffness and crushing load in the simulation of the mapped FE-model (same for shell or beams).
 - Influence of axial yarns → element length of the target mesh
 - Influence of matrix-rich zones → scaling factors (for the beam radius or the shell element thickness)



Content

1. The research campus ARENA2036 and the project DigitPro
2. Generating the finite-element model of a braided tube on the mesoscale
3. Mapping meso-macro with ENVYO for the structure simulation
4. Conclusion and future perspective




Conclusion

- The potential of the mapping tool ENVYO is investigated within the project DigitPro.
- The yarns orientations of mesoscopic models can be mapped on a target mesh for structure simulation.
- ENVYO offers several mapping alternatives:
 - Mapping shells-on-shells or beams-on-shells,
 - Layered-shell or stacked-shell approach,
 - Mapping of resin-rich zones (manufacturing effects),
 - Scaling factors for the beam and shells during the mapping,
 - ...
- The mapping approach allows considering potential effects of complex fibre architectures on the mechanical behaviour of composite structures.



Future perspectives

- More detailed investigation will be performed on the mapping tool in order to define mapping rules for braided composites:
 - Influence of the element length of the target mesh,
 - Influence of the scaling factors...
- The mapping tool will be developed to consider further manufacturing effects.
- The prediction potential will be investigated with other braided crushing tube (braid angles of 45° and 55°)
- The results will be validated within the closed process chain on generic components and real composite structures.



Mapped generic braided component

Thank you for your attention!

ARENA2036 DigitPro



FORSCHUNGS
CAMPUS

öffentlich-private Partnerschaft
für Innovationen



PTKA
Projektträger Karlsruhe
Karlsruher Institut für Technologie

Mathieu Vinot
mathieu.vinot@dlr.de

German Aerospace Center (DLR)
Institut of Structures and Design
Pfaffenwaldring 38-40, 70569 Stuttgart

