





# CONSIDERING BAKE HARDENING FOR DEFORMED SHEET STEEL

**A phenomenological approach**


Daniel Riemensperger

Adam Opel AG


# MOTIVATION



## Capturing local property distribution



# BAKE HARDENING(BH) EFFECT




- Accelerated ageing by movement of carbon atoms in solid solution during paint baking
- Carbon atoms attach to dislocations
- Movement of dislocation hindered  
→ Increase of resistance to external load

# MECHANICAL EFFECTS OF BH





- Significant increase of yield strength
- Mild increase of tensile strength
- Reduction of A80 fracture strain
- Increase of upper yield strength
- Lueders bands
- Increase of anisotropy



Bake-Hardening Effect of Dual Phase Steels (SAE 2009)

(2)




# STANDARD MEASUREMENT OF BH



## Determination of BH-values

acc. to EN 10325

- Difference in yield strength of unbaked and baked condition → BH-value
- Part of standard test matrix
- Values in engineering stress → transferred to true stress



Fließkurve u		(Kurven siehe Anhang)	
× BH0	[N/mm <sup>2</sup> ]	76	R <sub>0,2</sub> [N/mm <sup>2</sup> ] nach 170°/25' 771
× BH2	[N/mm <sup>2</sup> ]	153	R <sub>2,0</sub> [N/mm <sup>2</sup> ] 932
			R <sub>0,2</sub> [N/mm <sup>2</sup> ] nach 2%/170°/25' 1085

	ENG	TRUE
BH0	76	77 MPa
BH2	153	142 MPa


# INFLUENCES ON BH





- Carbon concentration
- Deformation prior to heat treatment (pre-strain)
- Time and temperature of heat treatment

## Yield strength increase



CR DP800 [MPa]



CR MP1000 LCE [MPa]



— BH0 — BH2 — BH5




# IMPACT ON CRASH PERFORMANCE





- Drastic reduction of ductility for some materials?
  - Uniaxial test with 5% pre-stretch  
→ High tendency for preliminary fracture
- BH effect increases heterogeneity of the part
  - Local yield strength varies  
→ Early necking

	CR MP1000 LCE		
	150°C/15'	170°C/20'	190°C/60'
BH0	19 MPa	60 MPa	165 MPa
BH2	60 MPa	100 MPa	166 MPa
BH5	100 MPa	114 MPa	204 MPa

(3)



Plastic strain



(3)


# IMPACT ON CRASH PERFORMANCE




- Drastic reduction of ductility for some materials?
  - Uniaxial test with 5% pre-stretch  
→ High tendency for preliminary fracture
- BH effect increases heterogeneity of the part
  - Local yield strength varies  
→ Early necking

	CR MP1000 LCE		
	150°C/15'	170°C/20'	190°C/60'
BH0	19 MPa	60 MPa	165 MPa
BH2	60 MPa	100 MPa	166 MPa
BH5	100 MPa	114 MPa	204 MPa

(3)



Plastic strain



(b) Docol 1200M (4)

Bake hardening effect in advanced high-strength steels, KARL LINDQVIST 2013

# PHENOMENOLOGICAL APPROACH




## Complex Problem

- Simple shift of curve not feasible
- Deformation of curve is pre-strain dependent
- Change has to be done element by element

## Simple Approach

- Translate bake hardening into work hardening
- Map result to element



# PHENOMENOLOGICAL APPROACH




## Complex Problem

- Simple shift of curve not feasible
- Deformation of curve is pre-strain dependent
- Change has to be done element by element

## Simple Approach

- Translate bake hardening into work hardening
- Map result to element



# BAKE VS. WORK HARDENING



## Work hardening

- Breakage of atomic bonds
  - Dislocations start moving or slipping across crystal planes  
→ Plastic deformation
- Dislocations interact among themselves and with grain boundaries / point defects  
→ Pile-up  
→ Increase of resistance to external load

## Bake hardening

- Accelerated ageing by movement of dissolved carbon atoms during paint baking
- Carbon atoms attach to dislocations
  - Movement of dislocation hindered  
→ Increase of resistance to external load



**→ Mechanical response quite similar**

# PHENOMENOLOGICAL APPROACH



## Apply BH as per rule

- Look up yield strength shift per pre-strain
- Look up equivalent bake-strain
- Update value in mapping file




# PHENOMENOLOGICAL APPROACH




## Example results

Visible increase  
of heterogeneity



initial



baked

# PHENOMENOLOGICAL APPROACH




## Example results

Visible increase  
of heterogeneity



initial



baked


# PROOF OF CONCEPT



- True stress BH data from data sheet

	ENG	TRUE
BH0	76	77 MPa
BH2	153	142 MPa

- \***MAT\_024** for unbaked material with GISSMO
- BH0
  - Add plastic strain to anticipate WH
- BH2
  - Stretch UT specimen to 2% pre-strain
  - Map deformed specimen




# PROOF OF CONCEPT



## 0. Test data

- BH0 → Mild
- BH2 → Strong

	ENG	TRUE	
BH0	76	77 MPa	
BH2	153	142 MPa	




# PROOF OF CONCEPT



## 1. Unbaked condition

Yield curve calibrated to tests





# PROOF OF CONCEPT



## 2. Baked condition (BH0)

Addition of homogeneous pre-strain





# PROOF OF CONCEPT



## 3. Baked condition (BH2)

- Deformed specimen with pre-strain
- Increase of pre-strain
- Visible increase of heterogeneity





# PROOF OF CONCEPT



## Comparison

- No change of local fracture strain
- Change of fracture location for BH2




# IMPACT ON GENERIC CRUSH TEST




## Bent component

Areas of deformation well defined




Comparison of 3 simulations

	WH	BH
		
	✓	
	✓	✓




# IMPACT ON GENERIC CRUSH TEST




	WH	BH
Blue		
Red	✓	
Green	✓	✓


max. pl. strain (Shell/Solid)



# IMPACT ON GENERIC CRUSH TEST



max. pl. strain (Shell/Solid)



# CONCLUSION

---



- BH is relevant for AHSS and UHSS
- Approach feasible
- Process simulation results mandatory for method
- Increasing effort in material characterization
- No increase in simulation time

Daniel Riemensperger

THANK YOU

### Sources

- 1 [https://en.wikipedia.org/wiki/Cottrell\\_atmosphere](https://en.wikipedia.org/wiki/Cottrell_atmosphere)
- 2 Bake-Hardening Effect of Dual Phase Steels (SAE 2009)
- 3 Bake Hardening Behavior of Advanced High Strength Steels under Manufacturing Conditions, Heike Kantereit (SAE 2011)
- 4 Bake hardening effect in advanced high-strength steels, KARL LINDQVIST 2013



AMPERA

