


# ARENA2036 DigitPro

Christian Liebold  
DYNAmore GmbH






Strategic partnership for new innovations and  
research on a new level

## DigitPro – Digitaler Prototyp

- closed simulation process chain
- from preliminary design to the final component
- micro, meso and macro modeling
- different simulation software tools
- HDF5 Format
- digital fingerprint


- braided components
- **Open-Reed-Weaving** components

**-50% development time**  
**mind. -10% weight**





DigitPro – Digitaler Prototyp

- determine material parameters on a micro-scale, using representative volume elements (RVEs)
- scripted TexGen program for RVE-generation of braided structures and ORW material
- Numerical estimation of material properties in tension, compression (axial and transversal) and shear





**make determined material data accessible for various material models**



## DigitPro – Digitaler Prototyp

- several process simulations will be investigated and improved
- various modeling techniques conceivable:
- braiding simulations with beam- and shell approach
- draping simulations with beam- and shell approach
- weaving simulations with beam-, shell or even solid elements



**consider results from process simulations in structural analysis**




DigitPro – Digitaler Prototyp

- Structural analysis can be performed with a large variety of material models available in LS-DYNA
- element sizes are much larger compared to the micro- or macro modeling approaches
- mapping and data storage is very important in order to:
  - Properly consider process simulation in structural analysis
  - Guarantee an easy data exchange btw. collaborating partners
- Homogenization methods are needed


**properly transform results from process simulations onto structural meshes**



- for composites, there exists a large variety of modeling approaches



- Automatic geometry matching implemented
- Considering roving width
- Thickness considerations from shell-stacking sequence and determination of pure resin areas



different results with different approaches

Infiltration Simulation




IFB  
Universität Stuttgart

Structural Simulation


- Mapping of the orientations from the braiding process simulation on the virtual structure





- Investigation of numerical approaches for the simulation of braided structures (CRFP)




DLR




Crash simulation




Structural analysis



Draping simulation




Braiding simulation





Virtual infiltration

DigitPro – Digital Prototyp

- a platform independent, HDF5 data storage container is defined within the project, allowing to access and track simulation results




development of a readable data exchange platform




DigitPro – Digitaler Prototyp

- Strategy development for the consideration of processing parameters within component optimizations




DigitPro – Digitaler Prototyp

- Within the ARENA2036 research campus, a multi-scale, integrative simulation environment is being established, allowing to consider multiple manufacturing processes
- The developed mapping, homogenization and data exchange platform is solver independent
- Optimization and CAM interfaces are under investigation




**DigitPro – the Digital Prototype: closing the simulation process chain**

# DigitPro – Digitaler Prototyp




Dieses Forschungs- und Entwicklungsvorhaben wird mit Mitteln des Bundesministeriums für Bildung und Forschung (BMBWF) gefördert und vom Projektträger Karlsruhe (PTKA) betreut. Die Verantwortung für den Inhalt dieser Veröffentlichung liegt beim Autor.

**DigitPro – the Digital Prototype: closing the simulation process chain**





Robot control system




Optimizing load paths & structure evaluation




Crash simulation



Draping simulation




Braiding simulation



Structural analysis



Virtual infiltration



# ARENA2036 DigitPro



FORSCHUNGS  
**CAMPUS**

öffentlich-private Partnerschaft  
für Innovationen



**PTKA**  
**Projektträger Karlsruhe**

Karlsruher Institut für Technologie

**Christian Liebold**  
Christian.liebold@dynamore.de

DYNAmore GmbH  
Industriestr. 2  
70565 Stuttgart