

14. LS-DYNA Forum, Oktober 2016, Bamberg

Erkenntnisse aus aktuellen Performance-Messungen mit LS-DYNA

Eric Schnepf¹, Dr. Eckardt Kehl¹, Chih-Song Kuo², Dymitrios Kyranas²

¹Fujitsu Technology Solutions GmbH, München

²ict information communication technology GmbH, Aachen



Agenda

- Fujitsu HPC Portfolio
- New PRIMERGY CX600 M1 with Intel® Xeon Phi™ 7200
- Performance Measurements with LS-DYNA
- Early Experiences with LS-DYNA on Intel® Xeon Phi™ 7200
- Best Practices

© 2016 FUJITSU

PRIMEFLEX for HPC Integrated HPC Solutions



Application Appliance		Reference Configuration			
Integration & Support services					
Assembly, Test & Delivery					
User workplace	HPC Gateway HPC Gateway Add-ons				
Management software	Batch	Operation	Administration		
System design	Head node Interconnect	Compute nodes Rack & Power	Storage Graphics		






HPC Simplicity & Expertise

Select Your Preferred Hardware Platform

density

Capability





© 2016 FUJITSU

PRIMERGY rack server

CELSIUS workstations


Fujitsu PRIMERGY CX2550 M2





Feature Overview

- Highest performance & density
 - Condensed half-width-1U server
 - Up to 4x CX2550 M2 into a CX400 M1 2U chassis
 - Intel Xeon E5-2600 v4 product family, 16 DIMMs per server node with up to 1,024 GB DDR4 memory
- High reliability & low complexity
 - Variable local storage: 6x 2.5" drives per node, 24 in total
 - Support for up to 2x PCIe SSD per node for fast caching
 - Hot-plug functionality for server nodes, power supplies and disk drives enables enhanced availability and easy serviceability



Usage Scenarios

Scale-out cloud infrastructure

HPC server farms

Intel® Xeon® E5-2600 v4 processors





Best combination of performance, built-in capabilities and cost-effectiveness

1.5 TB RAM with 2,400 MHz speed (DDR4)

}}

Accelerate 'in-memory' solutions

14 nm manufacturing process

>>

Improved energy efficiency

Up to 22 cores and 55 MB cache

>>

Boost your general computing performance by about 20%

Intel® Turbo Boost Technology 2.0


}}

Performance that adapts to spikes in your workload

Intel® Advanced Vector Extensions 2 (AVX2)

}}


Achieve higher throughput in technical computing



Intel® Xeon Phi™ 7200 Processor A Highly-Parallel CPU







¹Reduced cost based on Intel internal estimate comparing cost of discrete networking components with the integrated fabric solution

Fujitsu PRIMERGY CX600 M1







The new platform for highly parallel computing

The FUJITSU Server PRIMERGY CX600 M1 is the perfect choice for highly parallel applications in the area of scientific research, product development and business intelligence.

Up to eight server nodes per 2U and Intel® Xeon Phi™ Processors make for new levels of compute density.

Performance Measurement Environment



	Intel [®] Xeon Platform	Intel [®] Xeon Phi [™] Platform
Chassis	Fujitsu PRIMERGY CX400	Fujitsu PRIMERGY CX600
Server	Fujitsu PRIMERGY CX2550M2	Fujitsu PRIMERGY CX1640
CPU	2x Intel Xeon E5-2660v4/2690v4	1x Intel Xeon Phi 7210
Memory	192GB	192GB
Storage	SATA DOM 64GB	SATA DOM 64GB
Max Power	429 Watt	270 Watt

Models



3 cars	0.8M elements	
Car2car	2.5M elements	
ODM-10M	10M elements	

Downloaded from http://www.topcrunch.org/benchmark_problems.sfe

Pure Performance Comparison



All results on Xeon Phi are preliminary and are expected to improve with the official V9.0 release

Please contact the author for actual information

: 2-socket Xeon node provides slightly higher performance than 1-socket Xeon-Phi node

^{*}Performance is defined to be the reciprocal of simulation time, i.e. excluding preprocessing time

Price Performance Comparison



All results on Xeon Phi are preliminary and are expected to improve with the official V9.0 release

Please contact the author for actual information

: Depending on the model, Xeon Phi can be more price-performance attractive than Xeon

^{*}Performance is defined to be the reciprocal of simulation time; Fujitsu internal cost calculation is used.

^{*}Price Performance = Performance / Price

Single-run Energy Consumption Comparison



All results on Xeon Phi are preliminary and are expected to improve with the official V9.0 release

Please contact the author for actual information

: Xeon Phi is more energy efficient in almost all cases

^{*}Taking only the simulation time into account

Model Preprocessing/Decomposition Comparison




All results on Xeon Phi are preliminary and are expected to improve with the official V9.0 release

Please contact the author for actual information

: It is better to decompose the model on a Xeon node, then simulate it on Xeon-Phi. This is because the I/O and decomposition phase do not scale on multiple cores.

Advancing the Standard Xeon Line





∴ Even with the same frequency and number of cores, the Broadwell architecture is still 15% faster than the previous Haswell generation

^{*}Performance is based on the simulation time. The preprocessing time follows the same pattern.

Best practices: Process Pinning



- The default launching mode of Platform MPI might oversubscribe CPU cores and hence hinders the performance
- Use mpirun flags:
 - -affcycle=core -affwidth=core
 - -affblock=1 -affstep=1
 - -affopt=v,coreindex

- With process-core pinning
- Without process-core pinning





© 2016 FUJITSU

Best practices: Model decomposition



- Deformation occurs the most at the frontier of both cars
- Cut the y-axis so each process calculates the same amount of deformations
- P-file: decomp { sy <scaling</p>





© 2016 FUJITSU

Best practices: Leverage AVX2/AVX512



- New hardware needs new code
- In particular wider vectorization
- AVX512 > AVX2 > SSE2



Conclusion



- When simulating model deformations, Xeon-Phi offers
 - Superior price-performance (for simulation)
 - Lower energy consumption
 - Higher space density
- For model decomposition, Xeon is still the better choice
- Broadwell offers 15% higher performance than Haswell with the same core count and frequency, yet is offered at a lower price
- Pay attention to
 - Process pinning
 - Model decomposition methods
 - LS-DYNA version with the most advanced instruction set

High Performance Computing with Fujitsu



Why PRIMEFLEX for HPC from Fujitsu?

- Benefit from
 - Supercomputing experience also in commercial deployments
 - established collaboration with leading ISVs
 - global HPC Competency Network



Compete effectively

 in your global market place
 with Fujitsu PRIMEFLEX for HPC









shaping tomorrow with you