TaSC[®] Product Status

Willem Roux LSTC

Abstract

The LS-TaSC product status is presented. The current capabilities are discussed together with illustrative examples and release dates. In addition, the current development directions, such as new capabilities and CAE integration, are also revealed.



LS-TaSC Status Willem Roux Collaborators: Imtiaz Gandikota, Liangfeng Luo, Philip Ho, David Wynn

TM





Today's talk



Current directions in topology Capabilities of the latest version New development

Current Directions

Multi-criteria / MDO Gas mileage mandates Automated design Faster, improved design cycle **Materials**

Composites and porous materials







The race is both to the able and the swift.

LS-TaSC have:

- Specifically developed for large, highly nonlinear problems. Valid for linear.
- Imbedded in the design process

New Team Members

Imtiaz Gandikota

- Started in August 2013
- Support for both LS-OPT and LS-TaSC
- Attila Nagy
- Starting soon
- Methods development, DSA, composites.
- Worked with Gürdal and Dave Benson.

Existing LS-PrePost collaboration

• Luo Liangfeng, David Wynn, and Philip Ho





Version 3.0

Available on the ftp site. Major New Features

- Free surface design of solids
 - Geometry definitions
 - Automatic mesh smoothing
- Integration with LS-PrePost

Several minor features.







Bonnet Case Study





One design for three nonlinear load cases, each with a constraints.

During the design process, the algorithm will remove 90%-99% of the structure. Mesh refinement is therefore required.

Example courtesy of JRL.

Load Cases

Load cases:

- Rear beam response
- Latch bend response
- Torsion response

Nonlinear including contact













Dynamic weighing



- Dynamic weighting makes sure that the structural design is valid for all load cases.
- Can be considered a variation on multi-criteria design, because the weighing is done considering response values.
- Chose load case weights w_i such that $k_1R_1 = k_2R_2$, with k chosen considering the bound on constraint R of load case *i*.



First phase



First phase has 10% mass fraction from initial design. Dynamic weighing considering the constraints bounds, but the constraints are not active in this phase, because the final design will be lighter.





10

Iteration

Iteration

15

Iteration

Phase II





Refined mesh of phase I design as initial design

A constraint bounds for each load case.

Dynamic weighing to balance the weighing of the multiple load cases.

Target mass fraction of 1% (10% of phase I final design).

Phase II

Mass fraction of 7% of original design (24.4% from phase I final design)









Phase II constraints

Beam response: $R1=6.69 \ (\leq 6.7)$ Latch bend response: $R2=-1.66 \ (\geq -1.7)$ Torsion response: $R3=17.9 \ (\leq 17.6)$







Mass redistribution and part mass.







Free surface design



- Redesign of the surface of solids to have an uniform stress (removing the stress concentrations).
- Similar to biological growth methods.
- Extrusion and symmetry geometry definitions are allowed.
- Casting and forging geometry definitions are implied. Retaining a good mesh is a key technology area. Very quick to set up the design problem.



Component example with the yellow surface selected for redesign. Setting up a problem consists of defining a surface.





Component shape design

Comparing the Von Mises stress at iteration 16 with the original design shows a 37% improvement.

37% stress reduction (87 down to 55)







Edge smoothing



The edge of the surface can be deformed. Below with and without edge smoothing.





Suspension example

Outer surface design

Nonlinear behavior.









Final von Mises stress





×.



	Time = 0.18027
Fringe	Contours of Effective Stress (v-m)
4.000e	max ipt. value min=7.59335, at elem# 87922
3.600e	max=417.94, at elem# 115247
3.200e	
2.800e	
2.400e	
2.000e	
1.600e	
1.200e	
8.000e	
4.000e	
0.000e	

×

LowerArm Pull







GUI



Demo by Imtiaz.

Version 3.1



User-defined results (MDO) More integrated post pro-processing Outer surface of design Revised constraint GUI panel Many topology methodology improvements



User results



Request from a large customer.

- Enable multi-disciplinary design with results from different software.
- User must convert results to an material utility value; you can, for example, incorporate DSA values from other disciplines.
- This is only for advanced users; should work for a large variety of cases.



LS-PrePost Integration



Post-processing is integrated.



Outer surface of design

- Various old capabilities:
- Can create a surface containing part.
- Matrix plot
- Optimum design with all elements







Outer surface of design



Create surface containing optimum design. It is possible to request for an iteration and variable value.

	o Iso- o
7	

π) ×
Itevation		
		20
D		
Iso-level		
0		1.0
	0.8	
Nodal av	eraging method	
O avera	ge	
• max/r	min	
	Create Clear Output Do	ine



Constraints Panel



- Reorganized for allow more types of constraints.
- In the past you were limited to stiffness and reaction forces.
- In the future any type of response will be allowed.
- Dynamic weighing will be moved to this panel.





Methodology improvements



New(ish) product for nonlinear problems, started of with the HCA methodology.

First we created a framework containing:

- LS-Dyna integration
- LS-PrePost integration
- Computational geometry
- Large models $(10^6 10^7 \text{ elements})$
- Distributed computing

Going forward a larger focus on the methodology.





Methodology improvements



- Version 3.1 contains large improvements in all aspects of the biomimetic topology methodology:
- Solid/Void scheme
- Constraints handling
- Variable bounds
- In the future we will have a mixture of biomimetic and DSA techniques.



Model size



The technology is being developed for very large models.

A model size of 5 000 000 elements is common.



Summary



LS-TaSC is for the topology and shape design of very large, nonlinear problems.

Version 3.0 is a big step forward containing:

- Free surface design
- LS-PrePost integration

The important features for version 3.1 are

- Important methodology improvements.
- User / MDO results
- Outer surface of optimum