


Implicit / explicit switching in LS-DYNA

Anders Jonsson, DYNAmore Nordic,
an Ansys company



- This presentation contains examples based on public FE-models:
 - 2010-toyota-yaris-detailed-v2j.zip
 - from The Center for Collision Safety and Analysis (CCSA) at the George Mason University (GMU) developed under a contract with the Federal Highway Administration (FHWA)
 - The work of the CCSA at GMU is gratefully acknowledged.
 - Honda Accord, [Oblique THOR Accord Model](#)
 - developed by EDAG, Inc. under sponsorship from NHTSA
 - Chevrolet Silverado (2007)
 - from the National Crash Analysis Center (NCAC) at The George Washington University (GWU).
 - The work of NCAC at GWU is gratefully acknowledged
- The FBO model was created by Eric Piskula, Ansys EMEA ACE
 - Eric's contributions are gratefully acknowledged

Implicit / explicit switching in LS-DYNA





Overview

- Introduction
- Different ways to switch
 - Dynamic Relaxation
 - Different options on `*CONTROL_IMPLICIT_GENERAL`
 - Multi-stage analysis
 - Using `*CASE` and `dynain.lsdyna`
 - Springback after forming analysis
 - ...
- Some differences between implicit and explicit
 - Making the simulation work for both implicit and explicit
- Summary

Introduction

Multi-physics capabilities and solvers in LS-DYNA





LS-DYNA Mechanical solvers

Explicit ...





LS-DYNA Mechanical solvers

... and Implicit



deg CA:0.0



LS-DYNA Mechanical solvers



Implicit and explicit

Explicit

- Functions of earlier configurations only

$$\mathbf{x}_{n+1} = \mathbf{f}(\mathbf{x}_n, \mathbf{x}_{n-1}, \dots, t_{n+1}, t_n, \dots)$$

- Equilibrium at time t

$$\mathbf{M}\ddot{\mathbf{U}}_t = f_{e,t} - f_{i,t} - f_{d,t}$$

- Conditionally stable: Δt_{crit}

Implicit

- Solve an equation system

$$\mathbf{0} = \mathbf{f}(\mathbf{x}_{n+1}, \mathbf{x}_n, \mathbf{x}_{n-1}, \dots, t_{n+1}, t_n, \dots)$$

- Equilibrium at time $t + \Delta t$

$$\mathbf{M}\ddot{\mathbf{U}}_{t+\Delta t} = f_{e,t+\Delta t} - f_{i,t+\Delta t} - f_{d,t+\Delta t}$$

- Can be made unconditionally stable

LS-DYNA Mechanical solvers



Implicit and explicit

Explicit

- Many small time steps
 - Possible to simplify elements, material models, contact algorithms etc.
- Direct solution
 - Efficient
 - Accurate
 - Decoupled → Easy to parallelize
- Sequential treatment of constraints
 - Penalty formulation for joints

Implicit

- Few large steps
 - Requires strong objectivity
 - Large strain increments
- Iterative solution of a non-linear equation system
 - Factorization of matrices
- Higher accuracy in elements, materials, contacts etc. beneficial for convergence
- Simultaneous treatment of constraints
 - Constraint formulation for joints

LS-DYNA Implicit and explicit


Getting along



Technical Guide

Guideline for implicit analyses using
LS-DYNA

Reference models for explicit
analyses using LS-DYNA



2023-02-15 v1.4

Copyright © 2023 DYNAmore Nordic AB


LS-DYNA

Copyright © DYNAmore Nordic AB 2022. All rights reserved.

2022-09-16

LS-DYNA / LS-PrePost

Guideline for implicit analyses using LS-DYNA



Copyright © DYNAMore Nordic AB 2022. All rights reserved.

2022-09-16

LS-DYNA / LS-PrePost

LS-DYNA implicit / explicit switching

Getting along

- The Guideline for implicit analyses using LS-DYNA contains Appendix F
- Implicit / explicit switching is described
- Including some examples
- Also Appendices D, E could be of interest


- > 1 Background
- 2 Overview
- 3 LS-DYNA database cards for different analysis types
- > 4 Set-up of some common implicit analysis types
- ✓ 19 Appendix F: Implicit / explicit switching
 - > 19.1 Dynamic relaxation
 - > 19.2 Manual implicit/explicit switching
 - 19.3 Automatic implicit to explicit switching
 - 19.4 Explicit analysis with intermittent eigenfrequency analyses
 - 19.5 A note on output when using implicit to explicit switching
- convergence problems
- > 17 Appendix D: Converting an implicit model to explicit
- 18 Appendix E: Converting an explicit model to implicit
- > 19 Appendix F: Implicit / explicit switching
- 20 Appendix G: Some comments on control card settings

Different ways to switch

Options for switching between implicit and explicit in LS-DYNA


Different ways to switch

Overview



Dynamic relaxation

Two-stage analysis



- Activated by $SIDR > 0$ on `*DEFINE_CURVE`
- Additional control parameters on `*CONTROL_DYNAMIC_RELAXATION`
- Load curves with $SIDR = 1, 2$ active
- Possible to specify separate implicit settings, `*CONTROL_IMPLICIT_..._DYN`
- Output may be requested by `*DATABASE_BINARY_D3DRLF`

- Load curves with $SIDR = 0, 2$ are active


Dynamic relaxation



For implicit / explicit switching

- See also previous webinars, on Damping and Dynamic Relaxation available from the Client Area
 - Hallén, A., Pre-tensioning and dynamic relaxation, Webinar 2022-12-01
 - Bernhardsson, A., Damping in explicit LS-DYNA, Webinar 2021-04-22
- The most common application of DR is explicit bolt pre-loading followed by an explicit main analysis
- Two cases for using DR for implicit / explicit switching
 - Explicit DR phase, followed by an implicit main simulation
 - Can be very efficient for bolt pre-tensioning
 - Implicit DR phase, followed by an explicit main simulation
- To use Dynamic Relaxation (DR) for implicit / explicit switching, the keyword `*CONTROL_DYNAMIC_RELAXATION` is required

Explicit Dynamic Relaxation / Implicit main run




*CONTROL_DYNAMIC_RELAXATION

- Use mainly implicit settings / control cards
 - Fully integrated elements
 - Mortar contacts – possibly add contact damping, $VDC \approx 10 - 40$
 - Mainly implicit control cards, from for example “Guideline for implicit analyses ...”
- *CONTROL_DYNAMIC_RELAXATION is required
 - $IDRFLG = 1$ to activate explicit DR
 - Start out with the default values for other variables
- Adding *CONTROL_TIMESTEP is recommended
 - $DT2MS < 0$
 - (Allow $\sim 5 - 10$ % added mass)

Explicit Dynamic Relaxation / Implicit main run

Example: Pipe joint


- M18x8
- Pre-tension: 99.2 kN
 - Using explicit DR
- Torque loading: 500 kNm
 - Implicit statics



Explicit Dynamic Relaxation / Implicit main run

Result: Pipe joint

- M18x8
- Pre-tension: 99.2 kN
 - Using explicit DR
- Torque loading: 500 kNm
 - Implicit statics




Explicit Dynamic Relaxation / Implicit main run




Results: Pipe joint

Bolt forces



Torque vs. rotation



Explicit Dynamic Relaxation / Implicit main run

Keywords

*INCLUDE

control_cards_nonlin.key

*INCLUDE

database_cards_static.key

*CONTROL_DYNAMIC_RELAXATION

\$# nrcyck drtol drfctr drterm tssfdr irelal edttl idrflg

1

*CONTROL_TIMESTEP

\$# dtinit tssfacs isdo tslimt dt2ms lctm erode ms1st

-5.E-7


*CONTROL_TERMINATION

\$ ENDTIM ENDCYC DTMIN ENDENG ENDMAS

1.

Set explicit time step

Activate explicit DR



Implicit Dynamic Relaxation / Explicit main run




*CONTROL_DYNAMIC_RELAXATION

- Use mainly explicit settings / control cards
 - Mainly explicit control cards, from for example “Technical Guide ... “
 - Add implicit control cards, from for example “Guideline for implicit analyses ...”
- *CONTROL_DYNAMIC_RELAXATION is required
 - *IDRFLG* = 5, to activate implicit DR
 - *IDRFLG* = 6, to activate implicit DR on only some parts of the model, as specified by *DRPSET*
 - Set *NRCYCL* = 1
 - *DRTERM* to specify time when implicit solution is completed
- *CONTROL_IMPLICIT_GENERAL_DYN is required
 - *IMFLAG* = 1
 - Set *DT0* (initial time step size)

Implicit Dynamic Relaxation / Explicit main run


Example: Fan Blade Out analysis

- Example provided by Erik Piskula, Ansys EMEA AC
 - His contribution is gratefully acknowledged
- Pre-tension: Centrifugal acceleration of the fan blades
 - Using implicit DR of a part set ($IDRFLG = 6$)
- FBO Analysis:
 - 5000 rpm
 - Element set at the base of a fan blade deleted
 - Explicit analysis, 10 ms



Implicit Dynamic Relaxation / Explicit main run

Results: Fan Blade Out analysis - preloading



Implicit Dynamic Relaxation / Explicit main run

Results: Fan Blade Out analysis – explicit main run



Implicit Dynamic Relaxation / Explicit main run

Keywords

```
*INCLUDE
control_database.k

*CONTROL_DYNAMIC_RELAXATION
$#  nrcyck      drtol      drfctr      drterm      tssfdr      irelal      edttl      idrflg
      1              1.              1.              5

$=====
$ Implicit LS-DYNA control cards (for Dynamic Relaxation)
$=====

*CONTROL_IMPLICIT_GENERAL_DYN
$  IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
      1      0.10      2      0


*CONTROL_IMPLICIT_SOLUTION
$#  nsolvr      ilimit      maxref      ddtol      ectol      rctol      lstol      abstol
      12      11      15      1.E-3      1.E-2      1.E-20
$#  dnorm      diverg      istif      nlprint      nlnorm      d3itctl
      1      1      1      3      4      1
$#  arcctl      arcdir      arcclen      arcmtch      arcdmp

$#  lsmtdd
      5

*CONTROL_IMPLICIT_AUTO
$  IAUTO      ITEOPT      ITEWIN      DTMIN      DTMAX      DTEXP
      1      100      20      1.E-5      -700.      0.

*DEFINE_CURVE_TITLE
Implicit DR timesteps
700, 1
....

*CONTROL_IMPLICIT_DYNAMICS_DYN
$  IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
```



Activate implicit DR

Recommended implicit settings (starting point)

Implicit Dynamic Relaxation / Explicit main run

Keywords



```
*INCLUDE
control_database.k

*CONTROL_DYNAMIC_RELAXATION
$#  nrcyck      drtol      drfctr      drterm      tssfdr      irelal      edttl      idrflg
      1              1.              1.              6

$#  drpset
      100

$=====
$ Implicit LS-DYNA control cards (for Dynamic Relaxation)
$=====

*CONTROL_IMPLICIT_GENERAL_DYN
$  IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
      1      0.10      2      0      0

*CONTROL_IMPLICIT_SOLUTION
$#  nsolvr      ilimit      maxref      dctol      ectol      rctol      lstol      abstol
      12      11      15      1.E-3      1.E-2
$#  dnorm      diverg      istif      nlprint      nlnorm      d3itctl
      1      1      1      3      4      1
$#  arcctl      arcdir      arclen      arcmtl      arcclmp

$#  lsmtl
      5


*CONTROL_IMPLICIT_AUTO
$  IAUTO      ITEOPT      ITEWIN      DTMIN      DTMAX      DTEXP
      1      100      20      1.E-5      -700.      0.

.
.
.
```

Part set for implicit DR

Activate implicit DR

Recommended implicit settings (starting point)



Implicit / explicit switching

`*CONTROL_IMPLICIT_GENERAL`, `*CONTROL_IMPLICIT_AUTO`

- Implicit / explicit switching by `*CONTROL_IMPLICIT_GENERAL`, variable *IMFLAG*
 - *IMFLAG* < 0: Curve with ID = -1**IMFLAG* selects implicit or explicit analysis
 - *IMFLAG* = 4: Start implicit, automatic implicit / explicit switching
 - *IMFLAG* = 5: Start implicit, automatic implicit / explicit switching, mandatory implicit finish
 - *IMFLAG* = 6: Explicit with intermittent eigenvalue extraction. Also requires `*CONTROL_IMPLICIT_EIGENVALUE`
- All options listed above require a double precision version of LS-DYNA
- Mind output timesteps on `*DATABASE_BINARY_D3PLOT`, `*DATABASE_...`
 - Small timestep often used in implicit analyses
 - Can cause very large amount of output data when applied to explicit analyses

Automatic implicit / explicit switching


`*CONTROL_IMPLICIT_GENERAL, *CONTROL_IMPLICIT_AUTO`

- The simulation starts out in implicit, switch to explicit when convergence fails
 - Use mainly implicit control cards
- Problem time must be physical time
 - The time scale must be in agreement with the physical time.
 - For example loading is applied in 1000 ms, or 10 s. The end time must be adjusted according to unit system
 - Time cannot be a load parameter from 0 to 1
- Switching according to `*CONTROL_IMPLICIT_AUTO`
 - Based on *kfail* number of failed attempts to find equilibrium
 - *dtexp* determines how long time to run in explicit
 - To make a “irreversible” switch, use *imflag* = 4 and set *dtexp* > *endtim*

Automatic implicit / explicit switching

Example: 3-point bending


- Elasto-plastic material
 - `*MAT_MODIFIED_PIECEWISE_LINEAR_PLASTICITY_RTCL`
 - RTCL failure used for demonstrational purpose in this case
- Dimensions: 50x50 mm profile (t = 2 mm)
L = 500 mm
- Prescribed displacement
 - target: 75 mm




Automatic implicit / explicit switching

Results: 3-point bending

Failed elements and solution method





3plot : Bending, RTCL failure.Increase motion, a : STATE 1 ,TIME 0.00000000E+00



Automatic implicit / explicit switching

Results: 3-point bending


Force vs. displacement



Automatic implicit / explicit switching

Keywords

```
*INCLUDE
control_cards_nonlin.key
*PARAMETER
Rdbparu, 2.E-3
*INCLUDE
database_cards_expl.key
*CONTROL_IMPLICIT_DYNAMICS
$  IMASS      GAMMA      BETA      TDYBIR      TDYDTH      TDYBUR      IRATE      alpha
    1                                0.5
*CONTROL_TERMINATION
$  ENDTIM      ENDCYC      DTMIN      ENDENG      ENDMAS
    250.E-3
*CONTROL_TIMESTEP
$#  dtinit      tssfac      isdo      tslimt      dt2ms      lctm      erode      mslst
                                -1.4E-7
*CONTROL_IMPLICIT_GENERAL
$  IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
    4          0.10      2          0
*CONTROL_IMPLICIT_AUTO
$  IAUTO      ITEOPT      ITEWIN      DTMIN      DTMAX      DTEXP      KFAIL
    1          100      20      1.E-5      -700.      100.      3
*DEFINE SUBSET TITLE
Time st *** Warning 60102 (IMP+102)
          failed to find equilibrium after 16 iterations **
...
-----
formulation switch at time = 1.7300E-01  IMPLICIT -> EXPLICIT
-----
```





Time step for the explicit phase

Activate auto switching parameters

Switching at specified times

*CONTROL_IMPLICIT_GENERAL


- Use implicit and explicit solver during specified times during the analysis
- Set *IMFLAG* = -LCID on *CONTROL_IMPLICIT_GENERAL
- Synchronize with keypoints using *DTMAX* = -LCID2 on *CONTROL_IMPLICIT_AUTO



Switching at specified times

*CONTROL_IMPLICIT_GENERAL, *CONTROL_IMPLICIT_AUTO


- Use implicit and explicit solver during specified times during the analysis
- Set *IMFLAG* = -LCID on *CONTROL_IMPLICIT_GENERAL
- Synchronize with keypoints using *DTMAX* = -LCID2 on *CONTROL_IMPLICIT_AUTO



Switching at specified times

Example: Headform impact after gravity loading

- Gravity loading is applied from $t = 0$ to $t = 1.0$ s
 - Implicit
- Switch to explicit at $t = 1.0$ s
- After that, the headform initial velocity is activated
 - Explicit impact simulation



Switching at specified times

Example: Headform impact after gravity loading

- Gravity loading is applied from $t = 0$ to $t = 1.0$ s (implicit)
- After that, the headform velocity is activated:

```
*INITIAL_VELOCITY_GENERATION
```

\$#	id	styp	omega	vx	vy	vz	ivatn	icid
86000107	1		11111.0				1	86000001

\$#	xc	yc	zc	nx	ny	nz	phase	irigid
							0	1


```
*INITIAL_VELOCITY_GENERATION
```

\$#	id	styp	omega	vx	vy	vz	ivatn	icid
86000107	1		11111.0				1	86000001

\$#	xc	yc	zc	nx	ny	nz	phase	irigid
							1	1

```
*INITIAL_VELOCITY_GENERATION_START_TIME
```

\$#	stime
	1.00001





Switching at specified times

Results: Headform impact after gravity loading



0:d3plot : NHTSA Accord and LST Free FMH, implicit : Scalar: : Magnitude of Displacements : : STATE 2 ,TIME 2.00000000E-02



Switching at specified times

Keywords

```
*INCLUDE
control_cards_nonlin.key
*PARAMETER
Rdbparu, 1.E-3
*INCLUDE
database_cards_expl.key
```

```
*CONTROL_IMPLICIT_DYNAMICS
$      IMASS      GAMMA      BETA      IRATE
      1          0.6        0.38        1


*CONTROL_TERMINATION
$      ENDTIM      ENDCYC      DTMIN      ENDENG      ENDMAS
      1.1
```

```
*CONTROL_TIMESTEP
$#  dtinit      tssfacc      isdo      tslimt      dt2ms      lctm      erode      mslst
      -5.E-7
```

```
*CONTROL_IMPLICIT_GENERAL
$      IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
      -701          0.10          2          0
```

```
*DEFINE_CURVE_TITLE
Implicit/explicit switch
      701
          0.
          1.
```

```
*DEFINE_CURVE_TITLE
Time stepping curve
      700
...
-----
formulation switch at time = 1.0000E+00      IMPLICIT -> EXPLICIT
-----
```



Time step for the explicit phase

Curve ID for specifying solver

Eigenvalue analysis and explicit


*CONTROL_IMPLICIT_GENERAL, *CONTROL_IMPLICIT_EIGENVALUE

- Explicit analysis
 - Explicit control cards
 - Use $SOFT = 2$ or Mortar contacts
- Eigenvalue analysis of the intermittent or final configuration
 - Set $IMFLAG = 6$ on *CONTROL_IMPLICIT_GENERAL
 - Set $NEIG = -LCID$ on *CONTROL_IMPLICIT_EIGENVALUES
- Notes:
 - Requires double precision LS-DYNA
 - If you want eigenvalues at the end time, then increase $endt$ by a small value
 - Added mass from explicit analysis is included in eigenvalue analysis

Eigenvalue analysis and explicit

Example 1: Explicit seating analysis and implicit eigenvalues


- Explicit analysis
- Pelvis of Hybrid III dummy pressed into seat
- 250 eigenvalues requested at end of analysis



Eigenvalue analysis and explicit


Result 1: Explicit seating analysis and implicit eigenvalues

Explicit pre-load



Eigenvalues (Mode 3, 11.4 Hz)

values, in expl : MODE 3 ,FREQUENCY 1.135418E+01 ,EIGENVAL



Eigenvalue analysis and explicit

Keywords

```
*INCLUDE
control_database.k


*CONTROL_TIMESTEP
$  DTINIT      TSSFAC          ISDO      TSLIMIT      DT2MS          LCTM      ERODE      MS1ST
                                -1.2E-06

*CONTROL_TERMINATION
$  ENDTIM      ENDCYC      DTMIN      ENDENG      ENDMAS
    1.0

*CONTROL_IMPLICIT_GENERAL
$  IMFLAG      DT0      IMFORM      NSBS      IGS      CNSTN      FORM
    6          0.10      2          0

*CONTROL_IMPLICIT_EIGENVALUE
$  NEIG
    -702

*DEFINE_CURVE_TITLE
Eigenvalues
    702
                                0.5          150.
                                0.9          250.
```



Eigenvalues in explicit analysis


Set NEIG = -LCID

Specify y eigenvalues at time x

Eigenvalue analysis after explicit forming

Example 2: Forming analysis of bumper rail

- Explicit analysis
- Eigenvalue analyses after completed process
 - Termination time extended
 - Contacts disabled
 - Eigenvalue analysis



Eigenvalue analysis after explicit forming

Result 2: Forming analysis of bumper rail

Explicit forming

Eigenvalues

- Mode 45, 95.5 Hz


0:d3plot : forming w. eigenvalues : STATE 1 ,TIME 0.00000000E+00



mass properties of part # 4
total mass of part = 0.11606955E-02

Check on unconstrained mass seen by implicit:


nodal mass = 1.0209E-02 rigid mass = 4.7331E-03 total mass = 1.4942E-02
rotary mass = 4.9718E+02



Eigenvalue analysis after explicit forming

Example 2: Forming analysis / multistage

- Forming: Explicit analysis
 - Single precision possible
- Final deformed shape, with residual stresses etc. is output in a dynain-file
 - Keyword:
`*INTERFACE_SPRINGBACK_LSDYNA`
 - Common practice in forming analyses
 - Used for springback analyses
- Separate eigenvalue analyses using dynain



Eigenvalue analysis after explicit forming

Result 2.2: Eigenvalues using `dynain` file

0:d3eigv : LS-DYNA eigenvalues at time 1.00000E+00 : Scale Factor 7.000E-01 : MODE 4 ,FREQUENCY 1.431376E+02 ,EIGENVALUE 8.088484E+05



- First non-rigid body mode, 143 Hz



```
m a s s   p r o p e r t i e s   o f   p a r t # 4
t o t a l m a s s o f p a r t = 0.11606955E-02
```

Check on unconstrained mass seen by implicit:

```
nodal mass = 1.1603E-03 rigid mass = 0.0000E+00 total mass = 1.1603E-03
rotary mass = 2.1284E-07
```

Eigenvalues after forming using dynain

Keywords


```
*INCLUDE  
dynain  
*INCLUDE  
blank.key.partsec  
.
```

```
*INCLUDE  
control_cards_linear.key  
*INCLUDE  
database_cards_static.key
```

```
*CONTROL_TERMINATION  
$   ENDTIM   ENDCYC   DTMIN   ENDENG   ENDMAS  
      1.0  
*CONTROL_IMPLICIT_EIGENVALUE  
$   NEIG  
      150
```

Final configuration of
the forming analysis

Guideline for implicit analyses using
LS-DYNA



Requested number of
eigenvalues

Multistage analyses

The `*CASE` / `dynain.lsd` - concept

- Analysis of a sequence of load stages is run as a sequence of analyses
 - Possible to mix implicit and explicit stages
 - A more intuitive way of setting up a load history
 - Clear definition of which features that are active in each stage
 - Reduce need for birth/death times of contacts, boundary conditions etc.
 - Stages are set up using the `*CASE` keyword
- Information is propagated from stage to stage using a binary `dynain` file
 - Contains deformations, stresses, history variables, contact state for **Mortar contacts only**, etc.
 - Can be opened for 3d visualization in LS-PrePost (from version 4.8)
 - Keyword: `*INTERFACE_SPRINGBACK_LSDYNA`
- Easy to re-use pre-tensioned configuration is obtained after each stage

Multistage analyses

The *CASE / `dynain.lsd` - concept


- *CASE in LS-DYNA
 - Functionality for setting up many analyses in one keyword file
- `dynain` files
 - A keyword file containing the final state of an analysis
- Combining *CASE and `dynain` files: a new approach for multi-stage analyses in LS-DYNA
 - For a background, see Borrvall, T., [Solution explorer in LS-PrePost- a GUI for Nonlinear Implicit FE](#), 12th European LS-DYNA conference, Koblenz 2019.
 - Webinar: “Load history management”, 2021-05-27
 - Webinar: “Simulation of ROPS and FOPS”, 2023-02-09
 - Appendix B of the “Guideline for implicit analyses using LS-DYNA”
 - Appendix X in coming revisions of the keyword manual



Multistage analyses for implicit/explicit switching




The *CASE / dynain.lsda - concept




Multistage analysis for implicit/explicit switching

Example: Gravity loading followed by moving barrier impact

- A Chevrolet Silverado is subjected to
 - gravity loading (Stage 1, implicit) and




- impact with a moving barrier (Stage 2, explicit)



Multistage analysis for implicit/explicit switching




Result: Stage 1 - Gravity loading



Multistage analysis for implicit/explicit switching

Result: Stage 2 - moving barrier impact




Multistage analysis for implicit/explicit switching

Keywords, stage 1: Implicit

```
*INCLUDE
control_cards_nonlin.key
*INCLUDE
database_cards_static.key
*CONTROL_TERMINATION
$   ENDTIM      ENDCYC      DTMIN      ENDENG      ENDMAS
      1.5
*DEFINE_CURVE_TITLE
Implicit_timesteps
700,
0.,0.05
.1,0.05
1.,0.1
2.,0.2
*CONTROL_IMPLICIT_DYNAMICS
$   IMASS      GAMMA      BETA      TDYDTH      TDYBUR      IRATE
      1         0.6       0.38       1.         1.2         1
*CONTROL_MPP_IO_NODUMP
...
*INTERFACE_SPRINGBACK_LSDYNA
$#   psid      nshv      ftype      _      ftensr      nthhsv      rflag      intstrn
      338       999       3         0         0         0         1         0
$#   optc      sldo      ncyd      fsplit      ndflag      cflag      hflag
OPTCARD      0         0         0         1         1         1
*INTERFACE_SPRINGBACK_EXCLUDE
$#
BOUNDARY_SPC_NODE
```

Implicit dynamics initially active
then ramped down



To get dynain.lsda file

Multistage analysis for implicit/explicit switching



Keywords, stage 2: Explicit

```
*KEYWORD
$=====
$ Silverado truck geo
$=====
*INCLUDE
case1.dynain.lsd
*INCLUDE
silverado_geo12.key.partsec
...
$=====
*INCLUDE
control_database.k
*CONTROL_TIMESTEP
$  DTINIT    TSSFAC      ISDO      TSLIMT      DT2MS      LCTM      ERODE      MS1ST
                                -1.5E-06
*CONTROL_TERMINATION
$  ENDTIM    ENDCYC      DTMIN      ENDENG      ENDMAS
    140.E-3
```

Pre-loaded configuration
from Stage 1



Multistage analysis for implicit/explicit switching



- Makes it possible to use your
 - preferred implicit control cards for the implicit stages, and
 - preferred explicit control cards for the explicit stages
- Possible to switch to under-integrated elforms for explicit
- Explicit stages can be run using single precision LS-DYNA
 - Or use different number of cores

Some differences

Differences in modelling possibilities between implicit and explicit

Some differences between explicit and implicit



- Boundary conditions
- Joints
- Contacts
- Elements
- Materials
- New option in R14
 - `*CONTROL_ACCURACY, IACC = 2`

Some differences between explicit and implicit



- Boundary conditions
 - Applied simultaneously in implicit
 - Sequentially in explicit
- Joints
 - Constraint based implementation in implicit
 - Penalty based in explicit


Boundary conditions

Multiple constraints on rigid bodies



Implicit

Explicit




Boundary conditions

Multiple constraints on rigid bodies



Implicit


Explicit



Joints

Boundary conditions, Joints

- Multiple constraints on rigid bodies
 - Implicit can handle multiple constraints as long as they are not in conflict
 - Explicit cannot
- Joints
 - Explicit uses a penalty formulation
 - Implicit uses constraints – redundant constraints are not allowed



- Boundary conditions
 - applied consistently in implicit
 - sequentially in explicit
 - For switching, apply a modelling technique suited for explicit
- Joints
 - Constraint based implementation in implicit
 - Penalty based in explicit
 - For switching, apply a modelling technique suited for implicit

Contacts




Contact definitions for implicit and explicit

- Sliding contact
 - For explicit, typically $\text{soft} = 2$ or $\text{soft} = 1$ is used
 - Optimized for performance, fast solution
 - See also Webinar "Contact settings for crash applications", 2023-02-23
 - For implicit, Mortar contact is strongly recommended
 - Optimized for implicit convergence
 - Works well also for explicit
 - See also Webinar "Mortar in explicit simulation", 2020-12-17
- Tied contact
 - Implicit uses a strongly objective formulation
 - Can handle finite rotations in each time step
 - Explicit uses an incrementally objective formulation
 - Differences rarely noted



Contacts


Sliding contacts: Timing comparison



Contacts

Switching contacts


- User Mortar during the implicit phase
- Activate explicit contact at start of explicit phase
- Let the Mortar contact overlap for some time
- Deactivate the Mortar contact a bit into the explicit phase



Contacts

Switching contacts

- User Mortar during the implicit phase
- Activate explicit contact at start of explicit phase
- Let the Mortar contact overlap for some time
- Deactivate the Mortar contact a bit into the explicit phase



Elements

Some differences between explicit and implicit

- Implicit
 - Fully integrated elements, typically: shell elform 16, solids -2
 - Higher order elements, for example solids elform 16.
- Implicit and $IACC = 1$ on `*CONTROL_ACCURACY`
 - Nodal averaged 1st order tet (solids elform 13) supports all materials
 - Automatic switching of element formulations, for example shell elform 2 to elform (-)16
 - Strong objectivity for many element formulations
- Explicit
 - (Used to be) under integrated elements, typically: shell elform 2, solids elform 1
 - Nodal averaged 1st order tet (solids elform 13) supports a subset of materials
 - For fully integrated shells, use elform -16 for consistency

Material models

Some differences between explicit and implicit

- Many material models are first implemented for explicit, then augmented for implicit
 - Tangent matrix
 - Some models requires complete re-implementation for implicit
- Implicit and $IACC = 1$ on `*CONTROL_ACCURACY`
 - Fully iterative radial return for `*MAT_24` and `*MAT_123`
 - Automatic switch of `*MAT_LOW_DENSITY_FOAM` to `*MAT_FU-CHANG_FOAM`
 - Switch `FORM` to 14 on `*MAT_FABRIC`, unless `FORM = ±14` already.
- In explicit, strain-rate dependency of hardening for (metallic) materials is commonly used
 - Hard to resolve high strain rates in implicit – may lead to inaccuracies
 - Use `IRATE` of `*CONTROL_IMPLICIT_DYNAMICS` to disable strain rate effects in implicit
- Some materials / combinations are not available in implicit
 - Solid elements + `*MAT_NULL` + `*EOS`

Some differences between explicit and implicit



Coming in R14: $IACC = 2$ on *CONTROL_ACCURACY


- Implicit/explicit and $IACC = 2$ on *CONTROL_ACCURACY
 - Use strongly objective tied contacts
 - Nodal averaged 1st order tet (solids elform 13) supports all materials
 - More features to come ...

Implicit / explicit switching in LS-DYNA

Summary

- Using LS-DYNA implicit and explicit together offers great possibilities
- Many ways of switching
- Most useful are
 - Explicit DR + implicit Main run, for e.g. bolt pre-tensioning
 - Implicit + automatic switch to explicit for e.g. material failure
 - Mind the time scale for loading
 - Multistage analysis
 - Offers greatest freedom
- Simulation model must work in both implicit and explicit
 - Boundary conditions – explicit modelling
 - Joints – implicit modelling approach
 - Materials, for example `*MAT_FABRIC`

Thank You



DYNAMore Nordic AB
Brigadgatan 5
587 58 Linköping, Sweden

Tel.: +46 - (0)13 23 66 80
info@dynamore.se

www.dynamore.se
www.dynaexamples.com
www.dynasupport.com
www.dynalook.com

© 2022 DYNAMore Nordic AB. All rights reserved.
Reproduction, distribution, publication or display of the slides and content
without prior written permission of the DYNAMore Nordic AB is strictly prohibited.

Find us on




DYNAMore worldwide
Germany ■ France ■ Italy ■ Sweden ■ Switzerland ■ USA


Applications

... notes?

- pre-tensioning, of bolts?
 - expl DR for bolt pre-tensioning, implicit main sim
 - impl. multistage, boltpre + expl. loading
 - create example of this, the profile w. bolts?
- gravity loading ...
- failure modelling / element erosion, by impl -> expl switch (auto)
 - 3pt bending from mesh convergence study




Implicit/explicit switching – different cases



Implicit/explicit switching

Dynamic Relaxation



- LS-DYNA, implicit and explicit, general introduction
 - important with LS-DYNA, use the best solver best fit for the present analysis
- Differences between implicit and explicit
 - Boundary conditions
 - Materials
 - Elements
 - Joints
 - Contacts
 - ...
- Switching
- Different ways to switch
 - Manual
 - Automatic
 - DR
 - Cases, multi-stage --- also general about multi-stage
 - Springback ...
 - ...
- Important things to think about
- IACC = 2, from R14, for compatibility

Document information



Doc. no.:

Revision: 1

Prepared for: LS-DYNA users

Project no.:

Approved by:

Release date: 230309

Distribution: Approved for public release

DYNAmore Nordic AB
Brigadgatan 5
SE-587 58 LINKÖPING
Sweden

Org. no. 556819-8997
EC VAT:
SE556819899701

Phone: +46 (0)13 236680
Fax: +46 (0)13 214104
E-mail: info@dynamore.se
Web: www.dynamore.se