

Automated material model generation in VALIMAT AUTOFIT & AUTOFAILUREFIT

Benjamin Hirschmann, C. Schober (4a engineering GmbH)
contact: benjamin.hirschmann@4a.at
12.10.2022



4a engineering GmbH
Industriepark 1
A – 8772 Traboch


Content

- Introduction / Motivation
- Isotropic Thermoplastics – isoP pro
 - Material Calibration Process
 - Material Models For Plastics
 - Failure Models
 - Failure Fit Implementation
 - Failure Fit Results
- Conclusion

Introduction / Motivation

- simulation processes more commonly used in product development
- plastics wide variety of behavior and customizable for the application
- → demand for calibrated material models
- Automation
 - reduce process times
 - reproducible quality


e.g. pedestrian safety



Source: https://technologietag.4a.at/images/tt2016/tt16_t1_v04.pdf

Material Calibration Process


PRO



<https://www.4a-engineering.at/downloads/testpackages.pdf>

Material Calibration Process


PRO




<https://www.4a-engineering.at/downloads/testpackages.pdf>

Commonly Used Material Models For Plastics in LS-DYNA®

- ***MAT_024 - The workhorse**
(***MAT_081, *MAT_089, *MAT_123, ...**)
- ***MAT_187 - The plastic expert**
- ***MAT_187L – efficient version (R12)**



Material model	yield surface	Visco-elasticity	Visco-plasticity	Comp./tension asymmetry	plastic Poisson's ratio
*MAT_024	von Mises	✗	✓	✗	0.5
*MAT_187	linear; parabolic; piecewise linear	✓ $E(\dot{\varepsilon})$	✓	✓	✓ $\nu_p(\varepsilon)$
*MAT_187L	linear	✓ $E(\dot{\varepsilon})$	✓	✓	✓ $\nu_p(\varepsilon)$



additional failure models

***MAT_ADD_EROSION**

- MXEPS maximum principal strain, ...

strain damage based






- *before R11 optional DIEM / GISSMO*
- *since R11 *MAT_ADD_DAMAGE_DIEM*
- *since R11 *MAT_ADD_DAMAGE_GISSMO*

Included eq. pl. strain



***MAT_024**

included damage model in

***MAT_SAMP-1(GISSMO like)**



- Idea: Run a Simulation with all failure cases where failure occurs → Extract the relevant history variables for the chosen failure model → Estimate failure model parameters
- Consists of 2 parts:
 - Data Extraction from Modell without failure
 - Failure Model Fitting



Failure Fit Implementation

Data Extraction – Element Histories


- Define output sets in area of interest
- Data Extraction with VALIMAT python module



VALIMAT

Element Histories

$p, \sigma_{VM}, \eta, \theta_{Lode}, \varepsilon_{vol}, \varepsilon_p, \dot{\varepsilon}_p, \varepsilon_I, \dots$



Additional element history sets for data extraction

p pressure
 σ_{VM} Von Mises Stress
 η stress Triaxiality
 θ_{Lode} Lode angle
 ε_{vol} volumetric strain
 ε_p equivalent plastic strain
 $\dot{\varepsilon}_p$ equivalent plastic strain rate
 ε_I maximum principal Strain


Failure Fit Implementation

Evaluation Times

Decide when failure should occur

- failure time from measurement
(force drop, manual)

Identification of failure	0 - Manual (point in time)
tend	0.013712
tfail	0.01114



- Combined value of measurement and simulation results
 - Work equal between Simulation and Test
 - Same displacement in Simulation and Test

Evaluation Times

$$t_{fail}, W_p, s_{max}$$

Failure Fit Implementation

Failure Model Evaluation – Simple Evaluation

- Failure Target Points

- max occurrence of value at failure time from each test in each case
- ignore not failed tests


- Failure Modell

- parameter equals history variable

- Fitting

- weight cases (equally, unequally, ...)

Failure Target Points



Failure Fit Implementation

Failure Model Evaluation – Max. equivalent plastic strain Evaluation

■ Failure Target Points

- failure dependent on multiple history variables → failure target points not obvious
- simplified approach: use element/integration point with maximum equivalent plastic strain

■ Failure Modell



- function of several history variables

■ Fitting


- weight cases (equally, unequally, ...)
- nonlinear least square fit

Failure Target Points

$$\varepsilon_f(\varepsilon_p, \dot{\varepsilon}_p, \eta, \theta_{Lode})$$



FailurePointEvaluation
SelectedModel: eqplst_4apointwiselinear_eqplstr_JC



Cases :

- TT_V3000_d00_C
- TT_V1_d00_C
- PT_V4400_I
- PT_V1_I

Failure Fit Implementation


Failure Model Evaluation – Max. equivalent plastic strain Evaluation




VALIMAT

- For the chosen load cases the stress states in the area of interest is similar
- For future developments
 - groupings in triaxiality buckets


tensile test TT




3-point bending 3PB



puncture test PT



Trixiality Factor (-p/vm)




Failure Fit Results


*MAT_024 + MXEPS – Simple Evaluation




VALIMAT




hardening




flow rule



yield surface



failure




◆♦♦ Mean value curve of measurements

— simulation results


(— single measurement curve)
▽ set failure time

Failure Fit Results

*MAT_187L + DIEM – Max. equivalent plastic strain Evaluation




hardening




◆◆◆ Mean value curve of measurements

flow rule





— simulation results

yield surface





(— single measurement curve)
▽ set failure time

failure



Summary/Conclusion

- Overview of material calibration process with VALIMAT
- Implementation of the Failure Fit in VALIMAT
 - gives reasonable results
 - reduces the total process time



Summary/Conclusion



Standardized material characterization packages for your individual material class

isoP


frP

foam

comP

<https://www.4a-engineering.at/downloads/matpackages.pdf>

Material Calibration increasingly automated with
AutoFit & Failure Fit



Thank you for your Attention!



more information on our software

The software interface displays three types of plots: Anisotropic (with axes α and η), Damage/Failure (with axes ε_p and η), and Hardening (with axes σ_{vm} and ε_p). The interface includes a navigation bar at the top and a footer with the URL www.4a-engineering.at/valimat.

